


Aqara


USER MANUAL




Product Introduction

The Aqara Doorbell Camera G400 is a newly upgraded wired smart doorbell, consisting of an outdoor main unit and an optional chime. It is equipped with a 3-megapixel lens and a 165° wide-angle field of view. Its image sensor adopts a 3:4 aspect ratio, capable of clearly presenting full-body images of visitors. On the basic security level, it supports local motion, person and intrusion zone detection. After activating HomeGuard services, AI functions such as package detection and facial recognition can be unlocked. Additionally, the G400 introduces quick reply function, allowing users to select recommended voice responses or customize theirs to answer visitors in the App. This product features dual-band 2.4/5GHz Wi-Fi 6 connectivity and IP65 protection rating, supports local recording on MicroSD card, and is compatible with the ONVIF protocol, enabling integration with third-party NVR or software for installations. Besides being able to have a battery-powered mode and requires a low-voltage or PoE power source for installation. This product is able to connect to Aqara Home, this product can also be integrated into third-party ecosystems such as Apple Home, Google Home, Amazon Alexa.

What's in the Box




Outdoor Doorbell



Outdoor Doorbell Buttons

1. Doorbell Button: Press once, and both the doorbell and chime will ring once simultaneously
2. Function Button: Long press for 10 seconds to reset the network, quickly press 10 times to restore factory settings
3. Tamper Detection Button: When the detection function is enabled in the app, if the outdoor doorbell is detected to be detached from the wall mount bracket, it will trigger an alarm sound from the doorbell


Chime



Chime Button


1. Short press the volume adjustment button once to cycle through volume levels
2. Short press the ringtone switch button once to cycle through ringtones
3. Long press the Ringtone Switch button for 10 seconds to unpair the chime from the doorbell

Doorbell and Chime Pairing



Simultaneously long press the doorbell button and the chime volume adjustment button for 5 seconds: Pair the doorbell and chime (a single doorbell can be paired with up to 5 chimes)


Backplate Bracket and wedge bracket




Product Installation

1. Choose Installation Location


When installing the doorbell on a yard wall or fence (at a location far from the wireless router with weak Wi-Fi signal coverage), it is recommended to power the doorbell and provide network connection using the PoE method as shown in the diagram below (PoE network cable installation should be completed in advance). The distance between the doorbell and the chime should be kept within 30m (when separated by only one wall with a thickness of ≤24cm).



When installing the doorbell at the entrance door (at a location close to the wireless router with good Wi-Fi signal coverage), you can use the low-voltage power (8-24V AC or DC) at the door position to power the doorbell, while connecting the doorbell to the router via your Wi-Fi network. The doorbell supports a dual-band 2.4/5GHz Wi-Fi 6 network, with a distance controlled within 15m (when separated by only one wall with thickness ≤24cm). You can adjust the signal strength at the door by moving the position of the indoor wireless router.




The recommended installation height for the doorbell is 1.3-1.4 meters from the ground to the top edge of the doorbell. The lower the installation position, the smaller the vertical blind spot.




2. Choose the Power Supply Method

Low-Voltage Power Supply Method


Please first remove the default waterproof silicone plug installed on the back of the doorbell (the default plug is designed to accommodate PoE power supply, with a network cable groove on the back of the doorbell)




Please select the fully enclosed waterproof silicone plug (without a network cable groove on the back) from the accessories in the packaging box, and snap it back into the groove on the back



Use a screwdriver to loosen the screws on the power terminal block, insert the U-shaped terminal into the gap between the screw and the terminal block, then tighten the screws. Be careful to avoid short-circuiting the power wires.



After connecting the end of the extension cord to the main power line, secure the wire nut over the connection point of the two wires and twist it tight. Then, tuck the extension cord portion into the wall cavity.



PoE Power Supply Method

1. Remove the default waterproof silicone plug installed on the back of the doorbell
2. Insert the network cable into the RJ45 port
3. Snap the silicone waterproof plug back into place, ensuring the surface is flat



The network cable can be routed through the cable outlet at the bottom of the doorbell, as shown in figure (1), or it can be folded into a U-shaped harness in the rear groove, adhering to the buried cable groove of the silicone waterproof plug, and finally passing through the wall via the wiring hole in the wall-mounted bracket (as shown in figure (2)).

3. Choose a Mounting Method for the Doorbell

Using Adhesive Mounting

Suitable for installation on wooden doors, tiles, or other flat surfaces where drilling holes is not convenient. The installation steps and diagram are as follows:

1. First, determine whether you need to install the 15° wedge bracket. The wedge bracket is suitable for adjusting the horizontal angle of the doorbell. The wedge bracket supports adjustment in both left and right directions; simply flip the wedge bracket 180° to adjust the left or right rotation direction.

Use the two shorter self-tapping screws (specification: K83*6*5.0 mm) from the accessories to securely fasten the wedge bracket and the backplate bracket together.

Remove the backing from the adhesive on the back of the wedge bracket, firmly attach the entire bracket assembly to a flat wall surface, and press down firmly.

Align and tighten the bottom of the doorbell with the bottom of the backplate bracket first, then snap the entire doorbell onto the bracket assembly.

If you don't need to install the wedge bracket, start directly from step three by attaching the backplate bracket to the wall, then snap on the doorbell body

Using the Drilling Method for Mounting

Suitable for the case when the installation surface is uneven or when there are high requirements for the overall stability of the device. The installation steps and diagram are as follows:

1. First, you need to determine whether you need to install the wedge bracket. If needed, the first step is to attach the mounting hole template to the installation surface.
2. Use a tool to drill holes in the wall at the two oval positions inside the mounting hole template (Note: if the installation surface is wood or other lightweight structure, you can directly use self-tapping screws to secure it without the need for additional holes or expansion plugs)

Hammer the expansion anchors (specification: D6*25 mm) into the holes, ensuring that the end of the anchor is flush with the wall surface. Use the 2 longer self-tapping screws (specification: K83*25*5.5 mm) from the accessories to securely fasten the wedge bracket to the wall

Then securely fasten the backplate bracket onto the wedge bracket.

If you don't need to install the wedge bracket, then in the first step, choose the two oval positions on the outside of the mounting hole template for drilling

4. Removing the Doorbell

To remove the doorbell main unit for maintenance, insert a pin into the small hole at the top of the doorbell to press the internal movable latch, then remove the doorbell main unit

5. Mount and Power On the Chime

Peel off the protective backing from the adhesive on the back of the chime, firmly attach it to a flat wall surface, and connect it to power.

1. App Download

Search for "Aqara Home" in the app store or scan the QR code below to download the "Aqara Home" app.

2. Add Device

Connecting to Aqara Home

Ensure that your phone is connected to the Wi-Fi network that the doorbell will be connecting to. When the doorbell status indicator light is flashing yellow, open the Aqara Home app. The device will be automatically discovered and displayed on the device addition page in the app. Select the discovered device and follow the app's prompts to complete the device connecting process. Alternatively, you can select the "+" in the top right corner of the app's home page, select "Doorbell Camera G400" and follow the app's instructions. After successfully connecting, the doorbell status indicator light will remain solid blue.

The doorbell main unit and chime have been paired at the factory, and users do not need to rebind them;

*When connecting to the app, you need to scan the QR code information on the back of the doorbell. Please complete the network connection before installing the doorbell;

*After the doorbell is powered on for 10 minutes without connecting to Aqara Home or another ecosystem, the device will enter a cut-off state indicated by a steady white light. If you want to make the doorbell re-enter pairing mode, please disconnect and reconnect the power, or quickly press the function button 10 times to restore the doorbell to factory settings. When the indicator light changes to rapid yellow flashing, you can add the device again.

*When pairing, please keep your phone as close as possible to the doorbell, and ensure that your phone's Bluetooth function is turned on and that the app is authorized to use the Bluetooth function.

Connect to Apple "Home" App

Open the Apple "Home" App, tap "+" in the upper right corner to enter the Add Accessory page, scan or manually enter the HomeKit setup code (HomeKit QR code) on the back of the doorbell to bind the device to HomeKit.

Common HomeKit addition failure reasons and solutions:

*Unable to add accessory: Due to repeated failed attempts, the error message cached by the iOS system cannot be released. Please restart the iOS device (iPhone or iPad) and reset the doorbell before trying again.

*Prompt "Accessory has been added": Please restart the iOS device and reset the doorbell, then add the device by manually entering the HomeKit setup code.

*Prompt "Accessory not found": Please reset the doorbell, wait for 3 minutes, then re-add by manually entering the HomeKit setup code.

*Note: Please keep the QR code on the product body safe. If the addition fails, please press and hold the product function button for 10 seconds to reset the network, then add the doorbell again.

3. Other Functions

For more device features, please log in to the Aqara Home app to explore.

Explanation of Indicator Light Statuses

Indicator Light Status	Device Status
Steady yellow light	Device is powered on normally and starting up
Yellow light flashing rapidly	Waiting for network connection
Blue light flashing rapidly	Connecting to network
Blue light flashing slowly	Network connection successful, account binding in progress
Steady blue light	Normal operation
Steady red light	The doorbell is being viewed or cloud recording is in progress
Yellow light flashing slowly	Firmware upgrade or in factory reset process
Steady white light	After 10 minutes of startup, network connection is still not completed
Steady green light for 2 seconds	Someone's ringing the doorbell
Off	Indicator light is turned off/Device is not powered on/Device is in sleep mode

Product Specifications

- Doorbell Camera G400
- Video Resolution: 1536*2048
- Viewing Angle: 165° (diagonal)
- PoE Input: IEEE 802.3af (48V)
- Power Input: 8-24V AC, 1.3A 50/60Hz or 9-24V DC, 0.8A
- Connectivity: Ethernet, IEEE 802.11 n/b/g/n/ac (w/ Wi-Fi 6 @2.4GHz/5GHz), Bluetooth, RF433MHz
- Local Storage: microSD Card (not included), CLASS 10 or above is supported, up to 512GB storage
- Operating Temperature: -20°C~50°C (-4°F~122°F)
- Operating Humidity: 0-95% RH, no condensation
- *The radio transmission equipment model approval code for this product is printed on the product body

Chime

- Power Input: 5V ~ 1A
- Transmission Mode: RF433MHz
- Operating Temperature: -10°C~40°C (14°F~104°F)
- Operating Humidity: 0-95% RH, no condensation

Works with Apple

The use of the badge "Works with Apple" means that this accessory has been specifically designed to work with the technology identified in the badge and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. HomeKit Secure Video supports recording up to 10 days of video and securely storing it in iCloud. You can view it in the Apple Home app on iPhone, iPad, or Mac. Additionally, you need to have a 50GB iCloud storage plan to support one camera, a 200GB storage plan supports up to five cameras, and 2TB supports an unlimited number of cameras. Recording videos does not count towards your iCloud storage space.

Apple, Apple Watch, HomeKit, HomePod, HomePod mini, Siri and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries.



The word mark and logos are registered trademarks of the Bluetooth SIG, Inc., and any use of such marks by Lumi United Technology Co., Ltd. is under license. Other trademarks and trade names are those of their respective owners.

Warning

1. Do not connect the doorbell to a power source exceeding 24V (non-PoE power supply), as it may result in device burnout or fire.
2. Do not install the doorbell in a position where the lens may be directly exposed to sunlight, as this will cause irreversible physical damage to the image sensor.
3. When installing the doorbell on the wall using adhesive backing, ensure that the installation surface is flat and clean, and that the adhesive has sufficient contact area with the installation surface. The installation surface material is best if it's smooth glasses, tiles, marble, latex paint wall, etc.
4. Do not install the product near heat sources;
5. When powering the doorbell with a DC power source, the power terminal blocks do not distinguish between positive and negative poles. Either terminal block can be connected to the positive or negative pole. Please ensure that there is no short circuit between the terminal blocks.
6. When using PoE to power the doorbell, please ensure that the length of the network cable between the doorbell and the PoE power supply device is ≤100 meters. It is recommended to use Cat5e or higher specification network cable;
7. Please do not attempt to repair this product yourself; this should be done by authorized professionals.
8. The Chime is suitable for installation at a height of ≤2 meters.

Online Customer Service: www.aqara.com/support

Manufacturer: Lumi United Technology Co., Ltd.

Address: Room 801-804, Building 1, Chongwen Park, Nanshan IPark, No. 3370, Liuxian

Avenue, Fuyangang Community, Taoyuan Residential District, Nanshan District,

Shenzhen, China.

Email: support@aqara.com

Made in China