

- **Send Photos/Videos**

(1) Select one or more photos; (2) Select the target device album; (3) Add a photo description; (4) Tap "Send".

Note: Photos and videos cannot be selected and sent at the same time at this time.

- **Create a New Album**

You can create a new album and send photo or video content to the specified album. On the smart display, you can set the Smart Display to play photos and videos of the specified album.


- **Sending History**


You can view the status of the photo sending task and resend photos/videos or delete sending records in the sending history list.

3.4 Manage the Calendar



3.4.1 Create New Calendar Items

- Click the "+" button in the lower right corner and select Event, Alarm, or Task.








• Event



• Alarm




• Task



3.4.2 Manage Members

Swipe right on the top of the Calendar page to enter the Member page, then tap the "+" icon at the bottom right to add members.

You may set nicknames, link email addresses and assign exclusive background colors for each member.



3.4.3 Import Third-Party Calendars


Supports importing third-party calendar data from your phone. Open the FotoCube APP "Home Page" - "Calendar" - "Import", and select the calendar types to be imported [\[Refer to 2.3.3 Import Calendars\]](#) .

3.4.4 Meal Plan

Supports creating personalized meal plans.

Open the app, go to Calendar > Meal Plan, then select Breakfast, Lunch, or Dinner to create a corresponding meal plan.


Users can also add meal photos and detailed descriptions to enrich their meal planning experience. This feature is exclusive to mobile devices.



3.4.5 Habits Plan


Supports the creation of a 30-day habit-building plan. Users can navigate to Calendar > Habits Plan, and click the "+ Add" button to create a new plan.

For plans that have already been created, users can click on the card to edit or adjust member information.



3.5 Manage Devices

- **Share the device pairing code**
Click to pop up the QR code and pairing code of the device. You can take a screenshot to share or copy the digital pairing code for sharing.
- **Switch Device Modes Remotely**
Select your favorite mode for the specified device, such as Photo Frame, Family Calendar, or Art Gallery.
- **Set Device Background Music Remotely**
Send audio content to the specified device as the background music of the device.
- **Remove a Linked Device**
Tap to remove the device.



4 Language Support

The FotoCube Smart Display supports multiple languages, including **English, French, German, Portuguese, Spanish, Italian, Russian, Japanese, Chinese, Polish, Romanian, Bulgarian, Hungarian, Czech, Dutch, Danish, Korean, Finnish, and Estonian.**

The language options are regularly updated to enhance the user experience (availability may vary depending on the device's software version).

5 Warranty, Compliance, Technical Support, and Safety Information

For detailed information on warranty, hardware compliance, technical support, and safety, please refer to the information included in the package.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF RADIATION EXPOSURE STATEMENT:

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.



SOFTWARE TECHNICAL SUPPORT

For assistance with software setup, account registration, Wi-Fi connection, app operation, or other software-related issues, please contact the FotoCube Technical Support Team.



Email: fotocubeuserqa@gmail.com



YEMSD AFTER-SALES SUPPORT

For product quality issues, damaged or missing parts, replacement requests, warranty service, or other after-sales inquiries, please contact the YEMSD After-Sales Support Team.



Email: support@yemsd-official.com