


DEKCO

HD wifi security camera **DC4L**

Quick Start Guide



 www.dekcolife.com

 support@dekcolife.com

 @DEKCOLIFE

 1-877-277-5797

DekcoCare

Hi Customer

Thank you for choosing DEKCO security products. We have always put our customers first and foremost.

There are 3 things you should know before using this product:

1. Micro SD card

If you don't have a Micro-SD card available at home now and don't want to spend extra time choosing one, please contact us directly. TIP: the Micro-SD card gotta be formatted after inserting it up.

2. Select 2.4G wifi

The product only supports 2.4G wifi, please select 2.4G wifi when setting up the app.

3. Select installation location.

Please use your mobile phone to test the coverage of the home wifi signal at the planned installation position before installation, so that the product can receive a better signal.

Get all the tutorial videos of using product including but no limit to set up the app, installation and format micro sd card, visit: **dekcolife.com/DekcoCare**

Join "DekcoCare" today as three ways below to get all of your problems solved by one-on-one live chat and phone service tech support.

Facebook: DEKCO life


Email: support@dekcolife.com

Tel: 1-877-277-5797

TABLE OF CONTENTS

- 01** What's Included P01
- 02** Product overview P02
- 03** App installation and Setup P03
- 04** Mounting the camera P04-05
- 05** Register an account P06-07
- 06** Set up WiFi for the camera P08-15
- 07** FAQ P16
- 08** Safety Statement P17

What's Included




Camera



Screw Pack



Warning Sticker



Power Adapter



Sticker





double sided adhesive



User Manual

Product overview



CAUTION: Please insert the Micro SD Card according to the direction shown in the diagram. Micro SD Card might JAM if inserted incorrectly and device could be damaged.

SD Card Port: Support micro SD card for local storage (Max 128GB).

Reset button: Used to restore the camera to factory settings (Press and hold on 5-8s).

CloudEdge App installation and Setup

Search " CloudEdge" on apple store or google play to download the app.


- from Google Play
- from Apple Store



Mounting the camera


Select Height and location

Hang dekcoCam 7-10 ft (78-118 inch) above the ground. This height maximizes the detection range of the motion detection of dekcoCam. Avoid placing dekcoCam under direct sunlight.



Make sure of the reserving wire length

Reserve 10cm of end wire, fix the bottom base, avoid wire damage when camera turns.




Test the Wifi signal at installation position

Use cell phone to test Wifi signal quality at the installation position before installing camera, make sure the Wifi router can provide good Wifi signal.



Register an account

The CloudEdge app that is necessary to operate the camera. Signing up for storage in the cloud is totally optional and is really not necessary when using an onboard Micro SD card.



1



2

3. Set up an "Nickname" and "Password" for your APP, click "Done" to complete.




3

Set up WiFi for the camera

1. Bring both your mobile phone and your DEKCO camera close to your router (max distance of 5 meters/16 feet).


Note: The DEKCO camera can only connect to a 2.4 GHz WiFi signal. It does not support using a 5 GHz signal. Therefore, please ensure you connect to a 2.4 GHz signal on your network as shown in the below illustration.



2. Log in to "CloudEdge", then tap the "+" icon in the center. Tap "Camera" to add device.



2-1



2-2



2-3

3. Reset the device and wait for a flashing RED indicator light, then tap "Next".



3

4. Selecting the Wi-Fi the device needs to be connected with (your home Wi-Fi), input the password and click "Next".



4-1



4-2

5. Use the DEKCO camera to scan the QR code on your mobile phone as noted below. When the scan is complete you will hear a prompt tone then push Next.



5-1



5-2

6. When connecting, as stated earlier, you should make sure that the router, mobile phone and the DEKCO camera and are as close together as possible (max 5 meters/16 feet). When a successful connection occurs a "click" will be heard and a checkmark will be noted as shown below. The DEKCO camera will show with a numerical name that can be changed to your likings such as Driveway Camera, Street View Camera or whatever.



6-1



6-2



6-3

FAQ

Q: The device cannot be previewed properly?

A: Check whether the network is normal, you can place the camera close to the router, and if not, it is recommended to reset the device and add it again.

Q: Why is it still in the list of devices after resetting?

A: The reset device only resets the network configuration of the camera, but cannot change the configuration on the App, remove the camera, and must be deleted by the App.

Q: How to "connect" the camera to another router?

A: First remove and reset the device on the App and then configure the device again by the App.

Q: Why doesn't the device identify the SD card?

A: It is recommended that the SD card be inserted when the power to the camera is off and that it is fully inserted correctly. Make sure the SD card has been formatted with FAT 32. If not, this can be done via the CloudEdge app.

Q: Why can't I receive notifications via the mobile phone's app?

A: Please confirm that the App has been running on the phone, and the relevant reminder function has been opened; Message notification and authority confirmation in the mobile phone system have been opened.

Safety Statement

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: (1) Reorient or relocate the receiving antenna. (2) Increase the separation between the equipment and receiver. (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. (4) Consult the dealer or an experienced radio/ TV technician for help.

FCC Radio Frequency Exposure Statement

The device has been evaluated to meet general RF exposure requirements. The device can be used in fixed/mobile exposure condition. The min separation distance is 20cm.

Notice: Shielded cables

All connections to other computing devices must be made using shielded cables to maintain compliance with FCC regulations.

DEKCO