







英文



<p style="text-align: center;">Open Ear Headphones</p> <p style="text-align: center;">OPENEAR Air G6</p> <p style="text-align: center;">User Manual</p>	<p>How to Wear</p>  <p>What's In the Box</p> 	<p>Specifications</p> <p>Model: OPENEAR Air G6</p> <p>Type: Open-Ear Wireless Headphones</p> <p>BT Version: V6.0</p> <p>Connection: ≈10m</p> <p>Play Time: ≥20h(70%volume)</p> <p>Charging Time: ≈50min</p> <p>Charging Voltage: DC 5V</p> <p>Waterproof: IPX5 rating</p>	<p>Button Control</p>  <p>Silicone Strap Usage</p> <p>For a smaller head circumference, use this silicone strap accessory to secure headphones better. Tie each end of the strap to the headphone band behind the ears.</p> 	<p>Operations</p> <p>Power On/Off</p> <p>Power On: Press & hold the MFB button for 3 sec, white led flashes. Prompt: dong x3.</p> <p>Power Off: Press & hold the MFB button for 3 sec, green led flashes. Prompt: dong x4.</p> <p>BT Connection</p> <p>Select "OPENEAR Air G6" in BT menu to connect. Prompt: dong x3.</p> <p>Battery Level Notification</p> <p>Automatically announce the real-time battery level of the headphones after power on.</p> <p>Battery 100%-70%: Prompts: battery high.</p> <p>Battery 69%-40%: Prompts: battery medium.</p> <p>Battery 39%-10%: Prompts: battery low.</p>
<p>Multi-point Connection</p> <ol style="list-style-type: none"> 1. Pair & connect device A. 2. Turn off device A's bluetooth. Pair & connect device B. 3. Turn on device A's bluetooth again and auto-reconnect. 4. Device A and B connect simultaneously. <p>Answer/Hang Up/Reject A Call</p> <p>Answer/Hang Up A Call: Click the MFB once.</p> <p>Reject A Call: Double click the MFB.</p> <p>Play/Pause Music</p> <p>Click the MFB once.</p> <p>Previous/Next Track</p> <p>Previous Track: Press & hold the button + .</p> <p>Next Track: Press & hold the button - .</p> <p>Volume Up/Down</p> <p>Volume Up: Click the button + .</p> <p>Volume Down: Click the button - .</p> <p>When the volume reaches the maximum, Prompt: maximum volume.</p>	<p>Activate Voice Command</p> <p>Quickly click the MFB for 3 times.</p> <p>Low Battery</p> <p>The green LED flashes three times every 3 minutes when the battery is lower than 20%, Prompt: low battery .</p> <p>Restore Factory Setting</p> <p>Under power-on status, press button + and - at the same time for 10 sec to reset. Prompt: Restore to factory setting / power on.</p> <p>Charge</p> <p>Please use DC 5V adapter for charging. Green LED is on charging. White LED is on after fully charged.</p> 	<p>Attentions</p> <ol style="list-style-type: none"> 1. Listening to loud music for a long time may cause discomfort, please use medium volume if possible. Do not use high volume for long periods of time. 2. Using headphones will affect your perception of the surrounding environment. Pay more attention when using headphones. 3. Do not remove or modify the headphone, as this may cause damage or burn out. 4. Do not throw, twist on headphones or put them into a fire. 5. Keep it away from fire, hydration and high pressure equipment. 6. Not suitable for children under 10-year-old containing small parts. 7. Do not classify it as household waste. Please send it to the local electrical equipment recycling station. <p>Note: The company does not assume any responsibility for the loss of personal property caused by the violation of the above warnings.</p>	<p>FCC Warning Statement</p> <p>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p>	<ul style="list-style-type: none"> - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help. <p>FCC Radiation Exposure Statement: The device has been evaluated to meet general RF exposure requirements. The device complies with the FCC Rules. Operation is subject to the following two conditions:</p> <ol style="list-style-type: none"> (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation.