

A quick note from us.

Big thanks for backing gomi.

To get started, simply connect your Tag to the Apple Find My app and hook it onto your keys, luggage, or even your pet. If they go missing, just use the app to play a sound or see their last location.

We are a small independent team doing things the hard way. We use waste materials and design for repair because we believe tech should actually last.

If you want to support our mission, please leave a review or tell a friend. It really makes a difference.

Tom & the gomi team x

STRUGGLING TO CONNECT?

If you're having problems connecting, turn off your phone and try again.

If it's still not working, scan the QR code below and watch the video guiding you step by step how to connect.



If this does not resolve the issue, contact us at support@gomi.design and we'll help you.

HOW TO SETUP YOUR GOMI TAG?

Open the Find My app on iPhone, iPad, Mac, or iCloud.

Go to Items.

In the popup menu, go to 'add other item', double click the button on the gomi tag, it should make a single chime sound.

'Wireless Tag' will appear, press connect.

Give it a name and choose an emoji.

Agree to add to add it to your Apple Account, so it then becomes owned by you.

Wait for it to Finish Setup.



DISCONNECT YOUR GOMI TAG?

Open the Find My app on iPhone, iPad, Mac, or iCloud.

Go to Items.

Click on the gomi tag you'd like to remove. Scroll to the bottom, click 'Remove Item'.

REPLACE A BATTERY?

Remove the screws on the back of your gomi tag.

Take out the battery and replace with a CR 2032 battery.

Place the negative side facing the circuit board.

Screw together, pushing the plastic against the metal.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.