


# HEART RACING CAR DRIFT

**Frequency Pairing Instructions:** The vehicle's power indicator light flashes when connected; the remote control's power indicator light flashes when not paired. Successful pairing results in both the vehicle and remote control indicator lights remaining on.

**Note:** Please turn off the switch after use to avoid depleting the battery.



## RC OPERATION AND INSTALLATION



### NOTICE:

1. Open the battery cover at the bottom of the remote control and insert two 1.5V "AA" batteries according to the positive and negative electrode indicators. (Not included)
2. Do not mix new and old dry-cell battery together in use.
3. Do not mix rechargeable battery and dry-cell battery together in use.

## OPERATION AND INSTALLATION OF RC CARS



### NOTICE:

Only use the special charger for battery charging, please take out the battery if not used for a long time.


### OPERATION INSTRUCTIONS:

Please ensure that the power switch is in the "ON" position. The remote control car will not function if the power switch is in the "OFF" position.

1. Push open the upper and lower latches of the battery module until you hear a "click," confirming that the latches are released.
2. Install the battery module along the guide slot in the battery compartment of the vehicle body, ensuring that the module's arrow points towards the front of the vehicle.
3. Lock the upper and lower latches until you hear a "click," confirming that both latches are in the locked position.

### FITTING:

- ① Type-C Cable × 1
- ② DC. 3.7V Batterie × 1



### Straight-line


fine-tuning lever




### Note:

If the remote control car cannot move in a straight line, please adjust the straight-line fine-tuning lever under the car. (Refer to the left image)



## RC OPERATION INSTRUCTIONS





Forward





Turn left





Turn right




Backward



Back left



Back right



FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.