

## FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with Part 15 of the FCC Rules and contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

# WIRELESS KEYBOARD AND MOUSE

## INSTRUCTION MANUAL



2/AA 1.5v Batteries Required

 **WARNING:**  
**CHOKING HAZARD**-Small parts.  
Not for children under 3 years.



## INSTALLING BATTERIES

- Wireless keyboard uses one AA alkaline battery.
- Wireless mouse uses one AA alkaline battery.

## INSTALLING BATTERY IN MOUSE

1. Open battery compartment on bottom of mouse.
2. Insert battery, aligning positive (+) and negative (-) terminals with corresponding markings in compartment.
3. Replace cover.

## INSTALLING BATTERY IN KEYBOARD

1. Open battery compartment on bottom of keyboard.
2. Insert battery, aligning positive (+) and negative (-) terminals with corresponding markings in compartment.
3. Replace cover.

## CONNECTING RECEIVER

1. Plug receiver into USB port of computer or adapter.

### WARNING:


- When the computer first installs the receiver driver, an installation driver will appear in the lower right corner of the computer display screen.
- Please do not disturb it at this time because there is an installation process for USB.
- Don't interrupt this process

## STORING RECEIVER

1. When finished using mouse, remove receiver from USB port.


**M** re receiver in slot on bottom of mouse.

## INCLUDES



## WIRELESS KEYBOARD

1. Num lock
2. Caps lock
3. Low power and wireless connection indicator light



- ① Left button   ② Right button   ③ Scroll wheel   ④ DPI button  
⑤ Battery compartment   ⑥ Receiver slot

\*\*\*Note: Remove protective film before use.

## SLEEP MODE

To conserve battery life, mouse will enter sleep mode when not in use for a period of 10 minutes. During sleep mode, mouse will not respond to movement. To exit sleep mode, click any button or scroll wheel on mouse.

## POWER-SAVER MODE

When receiver is disconnected from USB port, such as during travel or when stored, mouse will enter power-save mode to conserve battery life. During power-save mode, mouse will not respond to movement, clicking or scrolling. To exit power-save mode, plug receiver into USB port.

## BATTERY INSTRUCTIONS

- Remove and immediately recycle or dispose of used batteries or batteries not used for an extended period of time according to local regulations and keep away from children. DO NOT dispose of batteries in household trash or incinerate.
- Even used batteries may cause severe injury or death.
- Call a local poison control center for treatment information.
- Product uses: 2/AA 1.5v Batteries Required.
- Non-rechargeable batteries are not to be recharged.
- Do not force discharge, recharge, disassemble, heat above 95°F or incinerate. Doing so may result in injury due to venting, leakage, or explosion resulting in chemical burns.
- Ensure the batteries are installed correctly according to polarity (+ and -).
- Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
- Replace all batteries at the same time.
- Clean the battery contacts and also those of the device prior to battery installation.
- Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.