


S608

Quick Start Manua

1. Product Overview

KINGBOLEN S6 Elite are intelligent diagnostic devices powered by Android 8.1. Featuring both touch and button operation modes, they deliver exceptional, professional and comprehensive diagnostic functions, including DTC reading and clearing, real-time data reading, actuation tests, etc. **The S608** can diagnose 4 ECUs in a vehicle.

2. Components & Controls



1. **Diagnostic Cable Interface:** Connect to vehicle's OBD port for diagnosis.
2. **Power/Screen Lock Button:** Press and hold for 3 seconds to turn on or off; Press once to lock or unlock the screen.
3. **Charging Port:** Type-C charging port for charging or data transmission.
4. **TF card slot:** Expandable storage slot supporting up to 128GB.
5. **Touch Screen:** 2-inch display for user interaction.
6. **Confirm button:** Execute the selected function.
7. **Direction button:** Control cursor movement for selection.
8. **Return button:** Cancel the current action or return to the previous menu.

3. Technical Specifications

Screen: 6.2 inches

Resolution: 1024*600 pixel

Working Environment: 0~50°C (32~122°F)

Storage Environment: -20~60°C (-4~140°F)



Working voltage: 9~18V

Working current: ≤ 1.2A

Supported Protocols: SAE J1850 PWM, SAE J1850 VPW, ISO 9141-2 ISO, ISO 14230-4 KWP, ISO 15765-4 CAN, CANFD

4. How to Use

4.1. Connect the device to your vehicle through the OBDII port/Data Link Connector (DLC)



OBD II Diagnostic Port of Automobile

The DLC is typically a 16-pin port where diagnostic code readers interface with the vehicle's onboard computer. The DLC is usually located within 12 inches of the center of the dashboard, under or around the driver's side in most vehicles. If the connector is not under the dashboard, a label may indicate its location. In some Asian and European vehicles, the DLC is located behind the ashtray, which may need to be removed to access the connector. If you cannot find the DLC, refer to the vehicle's service manual for guidance.

4.2 Turn the vehicle ignition on.


Note: It is not necessary to start the engine.

4.3 Power on the device.



4.4 Once the Android system starts, set the language and Wi-Fi.

The device will then display the main interface. Select the desired function on the interface to access the corresponding diagnostic feature.



5. Functions Description


5.1 Diagnos

It is the primary function of this device, offering two ways to access the function menu: automatic scanning of the Vehicle Identification Number (VIN) to identify the vehicle's make, model, and year, and regional model filtering, which allows users to select car models by region and access the diagnostic software for fault diagnosis.

5.2 OBD


On-Board Diagnostics (OBD) is a system present in most modern vehicles that monitors and diagnoses the performance of various components. It enables mechanics and vehicle owners to access real-time data, making troubleshooting more efficient. OBD provides critical information about engine speed, fuel efficiency, emission levels, and sensor readings. Additionally, it detects and displays fault codes, allowing technicians to identify and resolve issues quickly.

Overall, OBD plays a vital role in vehicle maintenance, supporting optimal performance and reducing emissions. When you press the OBD button, the device will automatically initiate the connection. Once the connection is successful, you will enter the OBD diagnostic page.




5.3 Maintenance

The Maintenance menu includes commonly used maintenance and reset functions to assist with regular vehicle upkeep. Different models contain different numbers of maintenance software, the S608 has 9 and S6 Elite has 15.




5.4 File

The function allows you to record and save data, including diagnostic reports, data streams, and images for future reference and analysis.




5.5 Repair info

The function enables you to access to a comprehensive Repair Info database, which includes DTC code libraries, vehicle coverage lists, and detailed user manuals.



5.6 I/M

Pull down the task bar, find the [I/M] icon, click it. You will then be connected to a live customer service representative who can assist you with any questions regarding the product.




5.7 Update

Use the Update function to check for and download new software and applications.


5.8 Feedback

If you encounter any unresolved issues or software bugs during diagnosis, you can use the Feedback function to send the last 20 diagnostic test records to our service team. Our team will analyze the data and troubleshoot the issue promptly to enhance the product and user experience.



5.9 Settings

The Settings menu allows you to customize the device according to your preferences. Configure options such as language, time zone, WiFi, business information, etc.



6. Q&A

Q: Why does the software upgrade fail?

A: Please check whether the device is stably connected to the internet.

Q: Why is there no power with the device after connecting it to the vehicle' s DLC port?

A: Please check whether the device is securely connected and verify that the vehicle' s ignition switch is turned ON.

Q: Why can't I access the vehicle ECU system?

A: Please check whether the vehicle is equipped with the system, whether the device is correctly connected, and whether the vehicle ignition switch is ON.

Q: Why does the system stop while reading the data stream?

A: This may be caused by loose connection. Please unplug the device and try again.

Q: Why does the screen flash when the engine ignition starts?

A: This is a normal occurrence caused by electromagnetic interference.

7. Warranty Terms

- The warranty is valid only for users who purchase KINGBOLEN products through authorized channels.
- KINGBOLEN provides a one-year warranty from the date of product activation, covering defects in materials or workmanship. The warranty period may be subject to adjustment in accordance with local laws.
- This warranty does not cover damage to the device or its components caused by misuse, unauthorized modifications, use for unintended purposes, or operation in a manner not specified in the manual.

- Compensation for damage to the dashboard caused by defects in this device is limited to repair or replacement. KINGBOLEN will not be liable for any indirect or incidental damages.
- KINGBOLEN reserves the right to determine the nature of any device damage based on its prescribed inspection methods. No agents, employees, or business representatives of KINGBOLEN are authorized to make any confirmations, notifications, or commitments regarding KINGBOLEN products without explicit authorization.

Service Line:(+86)0755-23445106

Customer Service Email: ediagtools@hotmail.com

Official Website: www.kingbolen.com

Youtube:Kingbolen auto scanner center

Facebook:@kingbolen.fans

Instagram:@kingbolen.fans

This device complies with Radio Equipment Directive 2014/53/EU

Product tutorials, videos, FAQs, and coverage lists are available on the official KINGBOLEN website.

Ediag Tools