

## SPECIAL INSTRUCTIONS FOR PARTICULAR TOP MOUNT SINK MODELS

### CAUTION

Leave protective tape on the sink when inverting over a benchtop and tracing its shape. The stainless steel will scratch if the sink slides across a hard surface.

Topmount sinks may also be known as “drop in” or “inset” sinks.

Topmount models with prefix PR, SN, NP, MO, DZ, PE, LL, UF, PL, MR, EL & TI.

These sinks will fit into standard 600mm bench tops.

Templates are available for download from [www.oliverisinks.com](http://www.oliverisinks.com)

Download PDF template from [www.oliverisinks.com](http://www.oliverisinks.com). If the template is not available, the cutout shape may be created by carefully inverting the sink onto the counter/benchtop and tracing around the perimeter. Cut the hole 10mm inside the traced line.

Many Oliveri sinks have waste outlets positioned to the rear of the bowls. Ensure the sink is correctly positioned when fitting.

### Unequal bowl depth:

Sinks that combine different sized bowls may also have unequal bowl depth. Waste plumbing will need to accommodate this variance. All sinks have a height adaptor included with the sink where needed.

### Solitaire models (LR)

LR510 & LR515 may be top mounted, each using a circular cutout 466mm in diameter. LR515 comes with a 32mm diameter taphole pre-cut in the tap landing. Mark the location of this taphole when trial fitting the sink. Then, drillout the counter/benchtop in the appropriate location so that the mixer tap can be solidly installed through both the sink and the counter/benchtop.

LR510 may also be under mounted in a solid-surface counter/benchtop using a circular cut out 454mm in diameter after edges are smoothed. Refer Oliveri undermount instructions for recommended installation methods.

## INSTALLER - PLEASE READ & FOLLOW THESE INSTALLATION INSTRUCTIONS

### FOR “TOP MOUNT” OR “DROP IN” SINKS

Please retain for consumer as care instructions are included



### CHECK MODEL

The model number on the sink packaging must match the model of sink the customer ordered. **Do not install if incorrect.**



### CHECK THE CONDITION

Inspect the sink for any visible defects. **Do not install the sink if defects are found.** Contact your sink retailer / point of purchase.



### AVOID CUTS

The perimeter and punch-outs on the sink may contain sharp edges. Handle the sink carefully to avoid personal injury.



### AVOID SCRATCHES

Stainless steel can be scratched if proper care is not taken during installation.

IT IS HIGHLY RECOMMENDED THE ACTUAL SINK BE PRESENT AT TIME OF CUTTING

### MATERIALS FOR FITTING THE UNDERMOUNT SINK:

- **Oliveri sink** (with correct tap holes as ordered) - includes mounting clips, sealing gasket, basket wastes and other accessories (depending on model).
- **These Installation Instructions**
- **Level** to check counter/benchtop & sink is installed level
- **Phillips head screwdriver** (#2 to tighten mounting clips)
- **Flat head screwdriver** (large - to tighten basket wastes)
- **Suitable sealant** (neutral-cure silicone sealant or equivalent)
- **Masking material** to protect counter/benchtop and sink from excess sealant
- **Additional Mounting Hardware** if fitting into thinner material. The clamps included with the sink require a minimum counter/benchtop thickness of 25mm / 1”.



Download cutout template files (PDF, DWG & DXF) from our website.

*Any advice, recommendation, information, assistance or service provided by Tasman Sinkware in relation to goods manufactured by it or their use and installation, is given in good faith and is believed by Tasman Sinkware to be appropriate and reliable. However, any advice, recommendation, information, assistance or service is provided by Tasman Sinkware without responsibility or liability.*

*Oliveri*

**AUSTRALIA**  
Head Office &  
Manufacturing Plant  
Tasman Sinkware Pty Ltd  
Regency Park SA

Phone: +61 8 8348 6444  
Fax: +61 8 8348 6495  
Email: [sinkware@oliverisinks.com.au](mailto:sinkware@oliverisinks.com.au)

[oliveri.com.au](http://oliveri.com.au)

**A member of the Fletcher Building Group.**

© Tasman Sinkware  
TF 08f May 2017



# FOLLOW THESE STEPS TO INSTALL THE OLIVERI TOP MOUNT SINK

IF COUNTER / BENCHTOP IS SUPPLIED WITH CUT-OUT, SKIP STEPS MARKED WITH\*



## CHECK SPACE & LEVEL

Use a level to check the counter/benchtop – if not level, have rectified. Ensure there is adequate space for tapware (including a splash back if specified). Check space for installation (underneath) and operation (above). Particular care must be taken when a thick splash back is used (it may interfere with tapware location and operation). Ensure the cabinet will not foul the sink mounting flange or basins.



## TEMPLATE \*

Cut out templates for your Oliveri sink are available online at [oliverisinks.com](http://oliverisinks.com). Use the product model number to find the template. Some sink templates apply to both left-hand and right-hand models sinks. **Ensure template is correct way around for your model.** (If no template is available, carefully invert the sink over the counter/benchtop and trace around it.)



## MARK CUT OUT \*

Carefully mark out the template (or follow drawing instructions). Once the hole is marked out, use the template to conduct a final check before cutting.


### IMPORTANT

**If you have traced the sink itself to mark your cut out, the hole must be cut 10mm inside the marked line.**




## CUT & FINISH HOLE \*

Re-check the position and cut out shape you have traced before cutting. Ensure there are no obstacles below that might interfere with cutting. Drill pilot holes to accept an appropriate cutting tool for the counter/benchtop material (wear suitable personal protection equipment). Cut just inside the template mark (or 10mm inside the sink tracing).




## TRIAL FIT THE SINK

Check that all clips are folded in so they will adequately clear the cut-out. Carefully position the sink into the cut-out to make sure it fits correctly. If the fit is not correct, remove the sink and proceed with remedial work. Perform another trial fit after corrections have been made.



## MASKING


If using a sealant, masking is necessary to prevent sealant overrun. It is recommended that the edge of the sink and the edge of the cutout are both covered with a suitable masking tape. This tape should be removed within 2 days of application.



## CHECK FOAM SEAL


Make sure the foam seal is intact and fits all the way around the sink with no gaps visible. This will ensure a water tight seal when the sink is properly tightened down to the counter/benchtop.

PR/SN models require sealant only and do not include a foam seal.



## ADDITIONAL SEALANT

Apply additional sealant / caulking compound around the join where the counter/benchtop and the stainless steel sink meet. Check that the caulking product is mildew resistant and is suitable for use on the counter/benchtop material and also is suitable for use on stainless steel. Clean away any excess before it dries. Note: Additional sealant should always be used if gaps are apparent after the sink has been clamped to the counter/benchtop



**FITTING THE SINK** If you choose to mount the tap / faucet onto the sink prior to fitting, take extra care as it will change the weight and balance of the sink. Position and align the sink correctly in the cutout and lower it onto the counter/benchtop. From underneath, tighten the clips with a screwdriver using a suitable tightening sequence (tighten from the centre of the sink to the outer edge) until the sink is secure and no gaps are visible. Take extra care if using power tools as over-tightening can damage clips.



**FINAL CHECK OF FOAM SEAL** With the sink tightened down. Visually confirm the foam seal is not protruding anywhere underneath. If it does, undo all the clips, reposition the foam seal and tighten down again. If the foam seal has been damaged, replace the damaged section. If the tap/faucet was mounted prior to fitting – check that the position is correct.



## PLUMBING & TAPWARE

**IMPORTANT** - Connections to plumbing should always be done by a licensed plumber. Fit supplied basket wastes to sink bowls. Install tapware according to manufacturer's instructions. Care should be taken when fitting wastes to the sink. Follow the instructions provided with the wastes.

## INSTRUCTIONS CONTINUE OVER PAGE

It is essential that the installation is waterproof and carried out in accordance with these instructions. Tasman Sinkware will not be held responsible for any damage caused by leakage or faulty installation.

## CARE INSTRUCTIONS FOR YOUR OLIVERI STAINLESS STEEL SINK

**AVOID CONTACT WITH ROUGH OR DIRTY SURFACES as new polished stainless steel will show scratches!**



### DO's

- Clean with soap & water (towel dry)
- Clean along the grain of the Stainless Steel
- Use a soft brush or sponge (old tooth brush)
- Wipe over with a glass cleaner (Windex is very good)
- Polish with a metal polish paste (Autosol / Brasso)
- Use a Liquid cleaner (Bon-Ami or Jiff)
- Use a granulated stainless steel cleaner (Essteel)



### DO NOT's

- NEVER use Steel wool
- Beware of harsh liquid cleaners
- Beware of grit within cloths and mineral deposits within water
- Avoid prolonged exposure to acids from Fruit, Fruit juices, Salts, Spirits, Bleach, Tea-bags
- Avoid prolonged contact with ordinary steel which can rust Tin Cans, Steelwool
- Do not keep harsh (acids or chlorine) chemicals under sink / laundry tub
- Do not leave chlorine/chloride chemicals on stainless steel surface
- Do not leave liquid soaps & cleaners to dry on stainless steel
- Do not use bleaches (White King, Domestos, Clorox)