



Atlas Headrest Speaker User Manual

V50710.1

Product overview




Charge the speaker




* Please fully dry the USB port before charging.

Power on and pair with the transmitter



1. In the powered-off state, press and hold the power button for 5 seconds. The speaker will automatically power on and enter pairing mode, and the LED indicator will flash red and blue rapidly.
2. Plug the transmitter into the USB port of your computer. The transmitter will automatically power on and enter pairing mode, and the LED indicator will flash red and blue rapidly. If it does not enter pairing mode, press and hold the MFB (Multi-Function Button) for 2 seconds.
3. Place the speaker close to the transmitter and wait for the pairing to complete. The LED will stop flashing once pairing is successful.

Power on and connect to the phone



*** To achieve audio-video synchronization, it must be used in conjunction with the included transmitter to achieve the lowest latency.**

1. Press and hold the power button for 5 seconds; the speaker will automatically power on and enter pairing mode, with the LED indicator flashing rapidly in red and blue.
2. Enable Bluetooth on your smartphone, search for 'Atlas Headrest', select it from the device list, and click to pair.
3. Bring the speaker close to the phone and wait for pairing to complete; the LED will stop flashing once connected.

FCC warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 -- Reorient or relocate the receiving antenna.
 -- Increase the separation between the equipment and receiver.
 -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 -- Consult the dealer or an experienced radio/TV technician for help.


This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
 (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment


* RF warning for Portable device:
 The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Disposal
 Always dispose of the used appliance at a recycling centre.
 Do not dispose the used appliance together with household waste.


In the box




Speaker




Audio transmitter



External microphone




USB magnetic power cable



User manual


| Button | Operation |
|--------|--|
| ① | Power on: Hold for 1.5s Power off: Hold for 3s Pairing: Hold for 5s when powered off |
| ② | Music mode: Short press to play/pause Music mode: Long press for 2 seconds to toggle between high volume/low volume mode. Phone Mode: Short press to answer/end call, Hold to decline incoming call. Phone Mode: riple-click to mute/unmute the microphone |
| ③ | Short press: Volume +; Long press: Next track |
| ④ | Short press: Volume-; Long press: Previous track |
| Reset | Hold both + and - simultaneously for 5 seconds to restore factory settings |

Audio transmitter




| LED Indicator | EN: Status |
|---------------|--|
| | Pairing mode (Long press the MFB button for 2 seconds) |
| | Connected |
| | Disconnected |
| | Restored factory default settings (Long press the MFB button for 7 seconds) |

Computer Settings



- Step 1: Right-click the speaker icon in the bottom right corner of the screen. And select "play-back devices".
 Step 2: Set "Atlas Headrest" as the "default device".

Installation and Usage



After pairing is completed, the speaker can be installed behind the seat headrest. The included microphone can be mounted as needed.

Warranty

Warranty service is limited to normal use. Any man-made damages such as from connecting to an unsuitable power source, using an unsuitable device, or not following the instructions, as well as damages that did not occur during shipping, repairs, and adjustments not approved by the company, damages from misuse, inattention, or improper installation may cause the warranty to be ineffective immediately. This warranty does not include shipping fees.

Operator: Atlas Headrest LLC
 Address: 72 W 64th Street Suite 330 Holland, MI 49423 USA

FCC ID: USB Wireless Dongle: 2BTX4-AERBTGDL
 Atlas Headrest Speaker: 2BTX4-AERBTSPK



MADE IN CHINA

