

AiseekTM


User Manual

Model: Multi-Mode Zigbee Gateway


Presentation

Red(Wi-Fi)


Blue(Zigbee+BLE)



Reset button



USB Type-C



Specifications

Model	Multi-Mode Zigbee Gateway
Material	ABS
Micro input	DC 5V/1A Tpye-C
Bluetooth	Low-Energy 5.0
Working Temperature	-20°C-85°C(-4°F-185°F)
Wi-Fi Frequency	2.4GHz 802.11b/g/n
Zigbee Frequency	IEEE 802.15.4
Size	60*60*14mm

How to connect the device

1. Scan the QR code below or search for "Smart Life" or "Tuya" App in your mobile app store





Press and hold the power button for 5 seconds to put the device into pairing mode

(Follow the steps as shown in the diagram)







Note: Before pairing, make sure to turn on WiFi and ensure it is 2.4 Ghz



2. Go to the page, click "+" and then click "Add Device"




3. The search device enters the pairing state.
The search device successfully clicks the device
selects 2.4 Ghz WiFi and enters the password.



4. The device is in the pairing process.
Please wait patiently. After the device is paired
click "Done".



5. Pairing successful! You can now add your Zigbee or Bluetooth devices.



2 Voice Control

The device supports voice control via Alexa and Google Assistant, please refer to "Using guidance" to activate. The "Using guidance" can be found through:

- a. Open the Smart Life app, select your plug in the Devices page.
- b. Tap setting icon in the top right corner.
- c. Tap "Using guidance" to follow on-screen instructions.

Troubleshooting

1. Fail to connect to Wi-Fi.

- a. Please keep your device within 100 feet of your phone.
- b. Make sure the Wi-Fi name and the password you entered is correct.
- c. Make sure the Wi-Fi you connect to is 2.4 Ghz
* 5 Ghz is not supported.

2. Lost W-Fi connection./Cannot use the device with the app.

a. Make sure your home Wi-Fi works well.

b. Check whether the Wi-Fi password has been modified.

c. Keep the distance between your device and phone as short as possible

d. Check if the device is connected to Wi-Fi via the indicator light. If the light flashes blue follow the steps above to reconnect the device to Wi-Fi.

Safety Instructions

- This device is recommended for use indoors and in a dry location only.
- Use this device exclusively within the rated output range stated in the manual.
- Please contact the AiSeek team for a replacement if there is any damage caused by transportation.
- Follow the manual for operation and keep it out of reach of children.
- Please do not disassemble the device. Otherwise, the device may get damaged or become a safety hazard.

FAQ

Q: I followed the instructions to put my device in pairing mode, but it still failed to be found. What can I do?

A: Make sure your device is powered on, and check if the indicator light is slowly flashing. If not, it means that the device has exited the pairing mode. Please hold down the reset button for five seconds to re-enter pairing mode.

If the info above doesn't clear up your problem you're welcome to reach us via your Amazon order or our email.

Features

You can easily check the status of your devices from anywhere, create smart scenes, and share device control with your family members.



Warranty: 12-Month Limited Warranty



Support: Lifetime Technical Support



Email: aiseeksupport@aiseeksmart.com



Official Website: www.aiseeksmart.com