

**OFF** Turn-off mode

Volume control mode

Left and right page turning mode

Up and down sliding mode

- Green and blue lights indicate normal battery levels.
- The red light indicates a low battery warning.
- Charging display in red when not fully charged.
- Full charge status displayed in green.
- The indicator light flashes while waiting to be paired.
- The indicator light is off when connected to the device, and it will flash once if press any button.



**Using it for two hours a day can last for about 20 days.**

## ■ For e-book readers, mobile phones, and tablets with Android system

Turn the toggle switch to the volume control mode, and the indicator light will display green.

Turn on the volume key page turning mode in the reading settings of the reading app.

Only supports left and right page c, does not support up and down page turning.



## ■ For smartphones and iPads with IOS system



TNote: Before using iOS devices, you need to open Settings - Accessibility - Zoom (Open)

After setting, tap the screen twice with three fingers to restore the normal screen ratio.

Turn the toggle switch to the left and right page turning mode, and the indicator light will display blue.

Select '**Simulate Page Turning**' mode in the reading settings.



To read in landscape mode, you need to toggle the switch to the up and down page turning mode.



## ■ Vertical screen flashing short video mode

Turn the toggle switch to the up and down sliding mode, and the indicator light will display green.

Before using iOS devices, you need to open Settings - Accessibility - Zoom (Open). After setting, tap the screen twice with three fingers to restore the normal screen ratio.



① 单击: 下一视频



② 单击: 上一视频

③ 单击: 暂停/播放  
双击: 点赞  
长按: 返回主页面

## ■ Photography and video recording modes

Turn the toggle switch to the volume control mode, and the indicator light will display green.

Open the camera interface on your phone or tablet, and press any page turning button.



**Notes:**

If the device cannot be paired properly, please check if there are too many Bluetooth devices connected to the device, if so, you can unpaired some infrequently used Bluetooth devices and then pair them again.

The remote will automatically shut down after 20 minutes when not in use.

**Before use, please ensure that the toggle switch is turned to the corresponding functional mode position.**

**Kind reminder:** If you encounter any problems during use, please send messages to our customer service asap (Please provide a detailed description of the problem encountered, as well as the brand and model of the device used. For iOS devices, please provide the system version, thus customer service will analyze the cause and provide a solution asap).

## FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.