


acer
OHR750
True Wireless Earbuds
User Manual
2A2P5-OHR750

INSTRUCTION MANUAL

Before using and operating the device, read and observe the following precautions to ensure the best performance of the device and avoid dangerous or illegal situations.

Product and Accessories



Remarks

The images are for illustration, Physical appearance and parameters may change with the upgrade. Please refer to the actual product.

Operation

No.	Function	Status	Operation	Prompt Tone
1	Turn on	Off State	Press touch point 3 seconds	Prompt Tone
2	Turn off	Standby/Playing	Press touch point 5 seconds	Prompt Tone
3	Pairing	Pairing	Blue & Red light flashes	Prompt Tone
4	Pickup call	Call coming	Single Click on touch point	
5	Hang up	Talking	Single Click on touch point	
6	Reject call	Call coming	Press touch point 2 seconds	
7	SIRI	Standby	Press touch point 2 seconds	
8	Volume Up	Talking/Playing	Double click the main earbud	Prompt Tone
9	Volume Down	Talking/Playing	Double click the deputy earbud	Prompt Tone
10	Play/Pause	Playing/Talking	Single Click on touch point	
11	Next Piece	Playing	Triple click the main earbud	
12	Last Piece	Playing	Triple click the deputy earbud	
13	Game Mode	Standby/Playing	Quadruple click	Prompt Tone

W/ENC W/Low latency

Earphone parameters

Model No. : OHR750 Talking time : 5hrs
Bluetooth Version : V5.4 Playing time : 5.5hrs
Chipset : jeli Standby Time : 2500hrs
Effective distance : 10M Charging time : 1.3hrs
Earphone capacity : 30mAh Waterproof level : IPX4
Charging box capacity : 250mAh Charging port : Type-C

Safety precautions

Before using and operating the device, read and observe the following precautions to ensure the best performance of the device and avoid dangerous or illegal situations.

Electronic equipment

Do not use wireless devices in places where the use of wireless devices is prohibited, otherwise it may interfere with other electronic devices or cause other hazards.

Impact on medical devices

- In medical and health care facilities where the use of wireless devices is prohibited, follow the rules of that location and turn off the devices.
- Radio waves generated by devices may affect the proper functioning of implantable medical devices or personal medical devices, such as pacemakers, cochlear implants, and hearing AIDS. If you use any of these medical devices, please consult the manufacturer about the restrictions on their use.
- The device contains magnetic material. Consult your doctor if this may affect implantable medical devices. • Keep at least 15 cm away from implanted medical devices (such as pacemakers, cochlear implants, etc.) when using this device.

Hearing protection

- Prolonged exposure to high volumes may cause permanent hearing damage.
- When you use headphones to listen to music or call, it is recommended to use the minimum tone required for the music or call to avoid damage to hearing.

Traffic safety

- Exposure to high volumes while driving can be distracting and lead to accidents.
- Comply with local or national regulations. Do not use this device while driving.
- Remember that driving safely is your first duty and do not engage in distracting activities.
- The car's electronics may fail due to radio interference from the equipment. Please contact the manufacturer for details. Wireless devices may interfere with the flight system of the aircraft. Please comply with the relevant regulations of the airline and do not use wireless devices in places where they are prohibited. Pay attention to your own safety and the safety of others if you use headphones while engaged in activities that require concentration, such as riding a bicycle or walking on or near roads, construction sites, railways. You should remove headphones or adjust the volume to ensure you can hear ambient sounds, including alarms and warning signals.

Operating environment

- Do not use the device in a dusty, wet, dirty place or near a magnetic field. Otherwise, the internal circuit of the device may fail.
- Keep the device away from appliances with strong magnetic fields or electric fields, such as microwave ovens and refrigerators.

Do not use the device during thunderstorms. Thunderstorms may cause equipment failure or electric shock hazards. It is recommended to use the equipment in the temperature range of 0° C to +45° C. When the ambient temperature is below +5° C, electricity performance is limited.

- Do not place the device in direct sunlight, such as the dashboard or window sill.
- Do not place the device in or near heat sources or exposed fires, such as electric heaters, microwaves, ovens, water heaters, fires, candles, or other places where high temperatures may occur.
- Do not place sharp metal objects such as pins near the handset or speaker of the device. Otherwise, metal objects may be attached and may cause injury.

Accessories requirement

- Use only accessories approved by the equipment manufacturer and compatible with this type of equipment. If other types of accessories are used, it may violate the warranty terms of the equipment and the relevant regulations of the country where the equipment is located, and may lead to safety accidents. For approved parts, please contact the manufacturer.
- Use the power supply (such as UL, CSA, VDE, and CCC) that is approved by relevant authorities and complies with electrical specifications and local regulatory requirements. Otherwise, the power supply may cause fire, explosion, and other hazards. Battery safety
- Do not disassemble or modify the battery, insert foreign objects, or immerse the battery in water or other liquids to avoid electricity Pool leakage, overheating, fire or explosion. Batteries can only be replaced by the manufacturer.
- Do not drop, squeeze, or puncture the battery. Avoid exposing the battery to high external pressure, which may lead to internal short circuit and overheating.
- Do not use the battery after it is immersed in water. At very low pressure, the battery may explode or leak. If the battery appears swollen, leaked, discolored, smelly, or other abnormal, do not continue to use the battery. Be careful and dispose of the battery immediately in accordance with local laws and regulations on battery handling.

Maintenance.

- If the product with lithium battery is not used for a long time, make sure to charge it at least once every three months.

- Keep the equipment and its accessories away from rain or moisture, which may cause fire or electric shock.
- Before cleaning and maintenance, stop using the device, shut down all applications, and disconnect all connections or cables from other devices.
- Do not use strong chemicals, cleaning agents, or strong detergents to clean the equipment or its accessories. Use a clean, dry, soft cloth to wipe the device or its accessories.
- Do not touch magnetic stripe cards (such as bank cards and phone cards) with the device for a long time. Otherwise, the magnetic stripe cards may be damaged by magnetic fields.
- Do not place the equipment and its accessories in areas with too high or too low temperature, otherwise it may cause equipment failure, fire or explosion

Operating environment

- Do not use the device in a dusty, wet, dirty place or near a magnetic field. Otherwise, the internal circuit of the device may fail.
- Keep the device away from appliances with strong magnetic fields or electric fields, such as microwave ovens and refrigerators. Do not use the device during thunderstorms. Thunderstorms may cause equipment failure or electric shock hazards. It is recommended to use the equipment in the temperature range of 0° C to +45° C. When the ambient temperature is below +5° C, electricity performance is limited.
- Do not place the device in direct sunlight, such as the dashboard or window sill.

Pay attention:

- To avoid accidental ingestion, keep earphones and accessories away from children and pets.
- The headset contains lithium batteries. If swallowed, it may cause serious injury to human body. Seek medical attention immediately.
- Minors should use the device under supervision.
- Please stop wearing and consult your doctor if you feel skin discomfort while

- To avoid accidental ingestion, keep earphones and accessories away from children and pets.
- The headset contains lithium batteries. If swallowed, it may cause serious injury to human body. Seek medical attention immediately.
- Minors should use the device under supervision.
- Please stop wearing and consult your doctor if you feel skin discomfort while

Pay attention:

- wearing due to individual differences.
- Do not open or remove the shell for
- maintenance without authorization, which may lead to the risk of fire or injury.
- If the product is damaged for any reason, it must be repaired by a professional or contact the manufacturer. There are no user replaceable parts inside.
- Do not place the device in a fire or at a high temperature. Placing the device in a fire or in an environment where the temperature exceeds 100° C will cause explosion.

Environmental protection

Do not dispose of the equipment and its accessories as ordinary household garbage. Comply with the local laws governing the disposal of this device and its accessories, and support the recovery action.

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. The use distance is not more than 5mm.