

SFVision V1.2 – User Manual

1. Product Description

The SFVision V1.2 is a cellular IoT tracking device designed to monitor produce and perishable goods during transportation and storage.

The device automatically collects environmental and motion data and transmits it to the SaveFruit platform using LTE Cat-1 connectivity.

No configuration is required by the user. The device arrives fully set up and ready for use.

2. Getting Started

Powering On

Press and hold the main button until the LED turns on.

The LED will flash slowly to indicate that the device is active and connected.

Normal Operation

Once powered on, the device automatically connects to the cellular network and begins collecting and transmitting data. No user action is required.

3. LED Indicators

Slow Flashing: Device is on and operating normally

Solid or rapid flashing: Temporary network search or startup process

4. Safety Information

Do not disassemble, crush, or modify the device.

Do not expose the device to fire, high heat, or liquids.

Discontinue use if the device is damaged.

5. Changes and Modifications Warning

Changes or modifications not expressly approved by Postharvest Applied Sciences SAPI DE CV may void the user's authority to operate the equipment.

6. Device Label Information

The device label includes the following information:

Model: SFVision V1.2

Brand: SAVEFRUIT

FCC ID: 2BU8HRGGAVON0310

7. Support Information

Postharvest Applied Sciences SAPI DE CV

Phone: +52 614 551 0384

Email: iot@postharvestsciences.com

8. FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user 's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Information (MPE)

This device has been tested and meets applicable limits for Radio Frequency (RF) exposure.

This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.