




Locator Bike Bell

User Manual



Locator Bike Bell Overview:



- | | |
|---|------------------|
| 1 | Metal Bell |
| 2 | Paddle |
| 3 | Turntable |
| 4 | Top cover |
| 5 | Bottom cover |
| 6 | Mounting bracket |
| 7 | Screw |


The Apple Find My network provides an easy, secure way to locate compatible personal items using the Find My app on your iPhone, iPod, Mac, iPod touch, or the Find Items app Apple Watch.

To use the Apple Find My app to locate this item, the latest version of iOS, macOS or watchOS is required.


Add Bike Bell to Apple Find My:

Update to the latest version of iOS or iPadOS. Turn on Bluetooth of your phone.

Pull out the mylar strip to power on.



Open the Find My app:



1. Tap "Items". Then tap "Add Items" or the "+" sign.
2. Tap "Other Supported Item".



3. Wait for.
4. Connect.
5. Fill in the name.




6. Choose an Emoji.
7. Wait for.
8. Finish.

Note: After removing the mylar, if not connected within 10 minutes, the finder will power off automatically. To restart it, please loosen the screws and reinstall the battery.

Specifications:

Model:	BBU18
Bluetooth version:	V5.2
Battery type:	CR2032 Replaceable
App:	Apple Find My
Operating System:	iOS 14.5 or above
Ambient Operating Temp:	14° F - 113° F
Size:	2.93" x 2.5" x 1.9"
Weight:	1.78 oz

Product Size:



Installation:




1. Pairing with iOS Find My app.
2. Mount the bell on your bike and tighten the screw.

Captive screw are used:




Screws fall out when the cover is removed. Captive screws do not fall out of the cover.


Battery Replacement



1. Use a screwdriver to loosen the screws.
2. Rotate the back cover counterclockwise to open, and remove cover.



3. Replace battery.
4. Put the back cover back in place.



5. Put the back cover back in place.
6. Tighten screws.

WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours**.
- **KEEP** new and used batteries **OUT OF REACH of CHILDREN**.
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.



Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.

Even used batteries may cause severe injury or death.

Call a local poison control center for treatment information.

⚠ WARNING:

Battery type : CR2032

Nominal voltage: 3V

Non-rechargeable batteries are not to be recharged.

Do not force discharge, recharge, disassemble, heat above 70°, or incinerate. Doing so may result in injury due to venting, leakage, or explosion resulting in chemical burns.

Ensure the batteries are installed correctly according to polarity (+ and -).

Do not mix old and new batteries, different brands, or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.

Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.

Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

Automatically Reconnect After Disconnection:

If the distance between the paired HP Locator and the iOS device exceeds the Bluetooth connection distance (which is 50 m in a closed barrier-free space), clicking "Play Sound" in the Find My app will prompt that the connection cannot be made. However, if the HP Locator and the iOS device are within Bluetooth connection distance, clicking "Play Sound" in the Find My app will make the HP Locator emit consecutive sounds, enabling you to easily find the items by following the sound.

Lost Mode - Find Things Easier:

The HP Locator can be put into Lost Mode. You will automatically receive a notification when it's detected by other devices in the Find My network. To activate Lost Mode, open the Find My app and follow the on-screen instructions, where you can add your phone number or email account. This way, if someone else picks up your HP Locator, they can easily contact you by following the instructions in Find My app.

Enabling "Notify When Left Behind":

Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch. Tap on your HP Locator from the list. Under "Notifications" enable

the "Notify When Left Behind" toggle. You will receive a notification when you leave your HP Locator behind and it's no longer in range of your device.

Enabling "Notify When Found":

Under "Notifications" enable the "Notify When Found" Toggle.

When your HP Locator is seen by another Find My network device, you will receive a notification of its location. Note: "Notify When Found" can only be activated when your HP Locator is out of range.

Remove the HP Locator From Find My App:

Open Find My app and select the "Items" tab. Tap on your Locator from the list. Please ensure "Lost Mode" is disabled. Scroll to the bottom of the screen and tap "Remove Item". A summary will open, tap "Remove" to confirm.

Power Off / Factory Reset the HP Locator:

Power off: Loosen the screw on the back, open the back cover, and remove the battery to power off the device.

Reset: Loosen the screw on the back, open the back cover. Quickly insert and remove the battery 4 times (you will hear a single beep upon each insertion). On the 5th insertion, keep the battery in. A different beep will sound to confirm successful reset.

Limited Warranty:

Your HP Product is warranted to be free from defects in materials or workmanship under normal use for one year. Your dated sales or delivery receipt is your proof of purchase. You may be required to provide proof of purchase as a condition of receiving warranty service. During the warranty period, if a defective HP Product covered by this Limited Warranty is returned to the designated Service Center, it will be repaired or replaced or, at the option of the Service Center, its purchase price will be refunded. No repair, replacement, or refund will be provided unless the defective HP Product is returned to the Service Center at your expense; for some HP Products, no return will be accepted unless the Service Center first provides you with a Return Material Authorization (RMA). If your HP Product has recurring failures, at the option of the Service Center, either you will be furnished with a different product that is equivalent in performance or you will receive a refund of your purchase price. Service Center support may be provided by an HP subcontractor or other third parties. Please see the Service Center information provided.

Where permitted by local law, HP Products and any replacement products or parts may contain new materials or used materials equivalent to new in performance and reliability. Replacement products or parts will have functionality at least equal to that of the product or part being replaced. Replacement products and parts are warranted to be free from defects in materials or workmanship for 90 days, or for the remainder of the warranty period for the HP Product which they are replacing or in which they are installed, whichever is longer.

This Limited Warranty does not include technical assistance. This Limited Warranty does not cover cosmetic damage, loss or damage in transit, or damage resulting from (a) accident, misuse, abuse, or other external causes; (b) product elements not supplied by HP; (c) improper site preparation or maintenance; or (d) modification or service by anyone other than HP, an HP Service Center or another HP-authorized service provider.

Limitations/Local Laws:

EXCEPT AS EXPRESSLY SET FORTH IN THIS LIMITED WARRANTY, THERE ARE NO OTHER WARRANTIES, EXPRESS OR IMPLIED, FOR YOUR HP PRODUCT. ALL OTHER WARRANTIES, INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE EXPRESSLY DISCLAIMED. ANY IMPLIED WARRANTIES IMPOSED BY LAW ARE LIMITED IN DURATION TO THE APPLICABLE WARRANTY PERIOD.

This Limited Warranty gives you specific legal rights, and it is governed by the laws of the state and country in which your HP Product was purchased. You may also have other rights that vary from state to state and country to country. You are advised to consult applicable state and country laws to determine your rights. Some states and countries do not allow any limitation on how long a limited warranty will last, or any exclusion or limitation of incidental or consequential damages. In such states and countries, some of the exclusions or limitations stated in this Limited Warranty may not apply to you.

Sole Remedies/No Incidental or Consequential Damages:

To the extent allowed by local law, the remedies provided in this Limited Warranty are your sole and exclusive remedies. These terms and conditions supersede any prior agreements or representations, including statements made in sales literature or advice given in connection with your purchase.

TO THE EXTENT ALLOWED BY LOCAL LAW, AND EXCEPT AS SPECIFICALLY SET FORTH IN THIS LIMITED WARRANTY, IN NO EVENT SHALL HP, ANY HP SERVICE CENTER OR ANY HP-AUTHORIZED SERVICE PROVIDER BE LIABLE FOR ANY DAMAGES CAUSED BY THE PRODUCT OR THE FAILURE OF THE PRODUCT TO PERFORM, INCLUDING ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, WHETHER BASED ON CONTRACT, TORT, OR ANY OTHER LEGAL THEORY, AND WHETHER OR NOT ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc. iOS is a trademark of Cisco and is used under license.

Federal Communications Commission (FCC) radio frequency interference statement information to the user

Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment in an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

NOTE: This device and its antenna(s) must not be co-located or operated in conjunction with any other antenna or transmitter.

RF exposure:

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.

Locate your Authorized Service Center

If you need support during the warranty period, locate the Authorized Service Center for this product at:

hpofficesupply.com

Or use the following contact information: USA: 833-523-0800

ROYAL®

Consumer Information Products, Inc.

HP Warranty Processing
50 Hilton Street
Easton, PA 18042

hpofficesupply.com

HP is a trademark of HP Inc. or its affiliates, used by Royal Consumer Information Products under license from HP Inc.

© Copyright, Royal Consumer Information Products, Inc. 2026
All Rights Reserved.

HP-LocatorBikeBell- BBU181M0714

Made in China






Locator Bike Bell

User Manual



Locator Bike Bell Overview:




1	Metal Bell
2	Paddle
3	Turntable
4	Top cover
5	Bottom cover
6	Mounting bracket
7	Screw

Find Hub helps you find and connect to what matters in a single, secure place. Find your belongings quickly and safely - even if your devices are offline. Plus, seamlessly and securely share your location with friends & family for peace of mind. All of your device location information remains private and safely stored.

1

Connecting to Google's Find Hub app:


Download and install the Find Hub app on Google Play.
Log in to the app using your Google Account.
Make sure your phone's Bluetooth and network connection are turned on.
Bring your Locator Bike Bell close to your phone.




Pull out the mylar to power on the Locator Bike Bell.
Wait for the Locator Bike Bell to appear on your screen. Tap Connect and follow the prompts to complete pairing.
In the Find Hub app, you can customize your device name and category.

Note: There is no button in the Find Hub app to manually trigger the pairing screen. It should automatically appear when your locator is activated near your phone.


2




1. Connect



2. Continue.



3. Open App



4. Finish.


Note: After pressing the button to turn on, if not connected within 10 minutes, the locator will power off automatically. To restart it, please press the power button again to turn it on.

3

Specifications:

Model:	BBU18
Bluetooth version:	V5.2
Battery type:	CR2032 Replaceable
App:	Find Hub
Operating System:	Android™
Ambient Operating Temp:	14° F - 113° F
Size:	2.93" x 2.5" x 1.9"
Weight:	1.78 oz


Product Size:



4

Installation:

Mount the bell on your bike and tighten the screw.



TIP: If the bike handlebars are too thin, you can add silicone pads.

Captive screw are used:




Screws fall out when the cover is removed.




Captive screws do not fall out of the cover.

5

Battery Replacement




1. Use a screwdriver to loosen the screws.




2. Rotate the back cover counterclockwise to open, and remove cover.




3. Replace battery.



4. Put the back cover back in place.



5. Put the back cover back in place.



6. Tighten screws.

6

WARNING

- INGESTION HAZARD:** This product contains a button cell or coin battery.
- DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as 2 hours.**
- KEEP** new and used batteries **OUT OF REACH of CHILDREN.**
- Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.



Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate. Even used batteries may cause severe injury or death.

Call a local poison control center for treatment information.

7

⚠ WARNING:

Battery type : CR2032

Nominal voltage: 3V

Non-rechargeable batteries are not to be recharged.

Do not force discharge, recharge, disassemble, heat above 70°, or incinerate. Doing so may result in injury due to venting, leakage, or explosion resulting in chemical burns.

Ensure the batteries are installed correctly according to polarity (+ and -).

Do not mix old and new batteries, different brands, or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.

Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.

Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

Automatically Reconnect After Disconnection:

If the distance between the paired HP Locator and the Android device exceeds the Bluetooth connection distance (which is 50 m in a closed barrier-free space), clicking "Play Sound" in the Find Hub app will prompt that the connection cannot be made. However, if the HP Locator and the Android™ device are within Bluetooth connection distance, clicking "Play Sound" in the Find Hub app will make the HP Locator emit consecutive sounds, enabling you to easily find the items by following the sound.

Enabling "Mark as lost" if your HP Locator is Lost:

Open the Find Hub app and select your HP Locator from the list.

Tap Mark as lost and follow the on-screen instructions to fill the contact information.

You will be notified if the Find Hub network locates your lost HP Locator.

Remove the HP Locator From Find Hub app:

Open the Find Hub app, select your Locator Bike Bell, tap the Setting button, then tap Remove from Find Hub and confirm.

Power Off / Factory Reset the HP Locator:

Power off: Loosen the screw on the back, open the back cover, and remove the battery to power off the device.

Reset: Loosen the screw on the back, open the back cover. Quickly insert and remove the battery 4 times (you will hear a single beep upon each insertion). On the 5th insertion, keep the battery in. A different beep will sound to confirm successful reset.

Limited Warranty:

Your HP Product is warranted to be free from defects in materials or workmanship under normal use for one year. Your dated sales or delivery receipt is your proof of purchase. You may be required to provide proof of purchase as a condition of receiving warranty service. During the warranty period, if a defective HP Product covered by this Limited Warranty is returned to the designated Service Center, it will be repaired or replaced or, at the option of the Service Center, its purchase price will be refunded. No repair, replacement, or refund will be provided unless the defective HP Product is returned to the Service Center at your expense; for some HP Products, no return will be accepted unless the Service Center first provides you with a Return Material Authorization (RMA). If your HP Product has recurring failures, at the option of the Service Center, either you will be furnished with a different product that is equivalent in performance or you will receive a refund of your purchase price. Service Center support may be provided by an HP subcontractor or other third parties. Please see the Service Center information provided.

Where permitted by local law, HP Products and any replacement products or parts may contain new materials or used materials equivalent to new in performance and reliability. Replacement products or parts will have functionality at least equal to that of the product or part being replaced. Replacement products and parts are warranted to be free from defects in materials or workmanship for 90 days, or for the remainder of the warranty period for the HP Product which they are replacing or in which they are installed, whichever is longer.

This Limited Warranty does not include technical assistance. This Limited Warranty does not cover cosmetic damage, loss or damage in transit, or damage resulting from (a) accident, misuse, abuse, or other external causes; (b) product elements not supplied by HP; (c) improper site preparation or maintenance; or (d) modification or service by anyone other than HP, an HP Service Center or another HP-authorized service provider.

Limitations/Local Laws:

EXCEPT AS EXPRESSLY SET FORTH IN THIS LIMITED WARRANTY, THERE ARE NO OTHER WARRANTIES, EXPRESS OR IMPLIED, FOR YOUR HP PRODUCT. ALL OTHER WARRANTIES, INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE EXPRESSLY DISCLAIMED. ANY IMPLIED WARRANTIES IMPOSED BY LAW ARE LIMITED IN DURATION TO THE APPLICABLE WARRANTY PERIOD.

This Limited Warranty gives you specific legal rights, and it is governed by the laws of the state and country in which your HP Product was purchased. You may also have other rights that vary from state to state and country to country. You are advised to consult applicable state and country laws to determine your rights. Some states and countries do not allow any limitation on how long a limited warranty will last, or any exclusion or limitation of incidental or consequential damages. In such states and countries, some of the exclusions or limitations stated in this Limited Warranty may not apply to you.

Sole Remedies/No Incidental or Consequential Damages:

To the extent allowed by local law, the remedies provided in this Limited Warranty are your sole and exclusive remedies. These terms and conditions supersede any prior agreements or representations, including statements made in sales literature or advice given in connection with your purchase.

TO THE EXTENT ALLOWED BY LOCAL LAW, AND EXCEPT AS SPECIFICALLY SET FORTH IN THIS LIMITED WARRANTY, IN NO EVENT SHALL HP, ANY HP SERVICE CENTER OR ANY HP-AUTHORIZED SERVICE PROVIDER BE LIABLE FOR ANY DAMAGES CAUSED BY THE PRODUCT OR THE FAILURE OF THE PRODUCT TO PERFORM, INCLUDING ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, WHETHER BASED ON CONTRACT, TORT, OR ANY OTHER LEGAL THEORY, AND WHETHER OR NOT ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Find Hub network requires location services and Bluetooth to be turned on. Requires cell service or internet connection. Works on Android 9+ and in certain countries for age-eligible users.

This product has been certified by Google to meet Find Hub network accessory specification. Google is not responsible for the operation of this product. Google is also not responsible for ensuring that the product complies with any applicable safety standards or other requirements. Google, Android, Google Play, Find Hub and Google Maps are trademarks of Google LLC.

Federal Communications Commission (FCC) radio frequency interference statement information to the user

Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment in an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

NOTE: This device and its antenna(s) must not be co-located or operated in conjunction with any other antenna or transmitter.

RF exposure:

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.

Locate your Authorized Service Center

If you need support during the warranty period, locate the Authorized Service Center for this product at:

hpofficesupply.com

Or use the following contact information: USA: 833-523-0800

ROYAL®

Consumer Information Products, Inc.

HP Warranty Processing
50 Hilton Street
Easton, PA 18042

hpofficesupply.com

HP is a trademark of HP Inc. or its affiliates, used by Royal Consumer Information Products under license from HP Inc.
© Copyright, Royal Consumer Information Products, Inc. 2026
All Rights Reserved.

HP-LocatorBikeBell- BBU18IM0715

Made in China

