


V30



V30 User Manual
Open Ear Headphones


V2.1 2025.04.21

In the Box

- Charging Case * 1
- Type-C Cable * 1
- Earbud * 2
- User Guide * 1

Note: Please remove the insulating film from the earbuds prior to their first use.

Product Introduction



First Use

Before the first use, please tear off the isolating film on the earbuds. Put the earbuds into the case, then charge both earbuds and charging case via supplied Type-C charging cable for at least 10mins (or after not use for a long time), do not take out the earbuds during this period.

Wearing

- Position the earbuds just above your ears, with the ear hooks facing downward.
- Gently rotate the ear hooks downward, following the contour of your outer ear auricle until they are securely positioned.
- Complete insertion.

Power On/Off


Power on

- Pick up buds from the charging case.
- Tap and hold for 2s(* Each bud needs to be powered on separately.)

Power off

- Put back into the charging case
- Not connected to any devices over 5mins
- Non-connected, tap and hold for 5s any buds (* Earbuds will be powered off simultaneously.)

Control



Music Control

- Play/Pause: Double-tap(R/L)
- Next Track: Triple-tap(R)
- Previous Track: Triple-tap(L)
- Volume +: Tap and hold(R)
- Volume -: Tap and hold(L)

Call Control

- Answer a call: Double-tap(R/L)
- End a call: Double-tap(R/L)
- Reject a call: Tap and hold for 2s(R/L)

Voice Control

- Activate/Stop voice assistant: Triple-tap(R/L)

Single earbud control

Both earbuds support independent use for mono music or calls. When used alone, the earbuds could not adjust the volume, only switch music to next song.

Bluetooth

After turning them on, search for the Bluetooth device "V30" on your cellphone to connect.

Reset

1. Symptom

When only one side play music. When you can't find "V30" on your device. Occur connection issues.


2. Solution

- Delete all "V30" on your phone and deactivate the Bluetooth setting.
- Quick click both earbuds 5 times simultaneously, their LED will flash red and blue light at the same time for 3 times to indicate that both earbuds are fully reset.
- Then put the earbuds in the charging case and charge them for a while. Now, pick up the earbuds to turn them on, activate the Bluetooth setting on your device and select "V30" to connect, it should work

Charging

Charging case battery status

- When the battery level is 21%-100%, the blue light will lasting 10 seconds then switch off.
- When the battery level is 0%-20%, the red light flashes rapidly for 10 seconds.




How to Check the Battery Level of the Charging Case?

When you place the earbuds into the charging case or when the charging case is being charged, please refer to the charging case's battery status.


Earbuds charging status

The earbud's red light will flash slowly and turn off when fully charged. The charging case's indicator light will turn off after displaying the battery status.



Maintenance

- Please remove the protective film before use, otherwise the earbuds will not be able to charge.
- Please clean the protective grille of both earbuds if the sound becomes low.
- If the earbuds can't be charged, please clean the magnet charging contacts on the earbuds and the charging pins on the case with alcohol wipes.



Safety Precautions

- Please prevent the device from being stricken, dropped, warped, soaked etc.
- Please do not dismantle the earbuds or charging case.
- Please stop using the device if it causes any discomfort or pain.
- Use DC 5V-1A chargers/adapters certified by a regulated manufacturer.

Battery Warning

Using the wrong battery can cause fire and other hazards (for example, in the case of some lithium battery types)

- Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
- Do not leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.
- A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

FCC Caution

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

ISED Warning

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- This device may not cause interference, and
- This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- L'appareil ne doit pas produire de brouillage, et
- L'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device is compliance with RF exposure guidelines, users can obtain Canadian information on RF exposure and compliance. Le présent appareil est conforme

Après examen de ce matériel aux conformité ou aux limites d'intensité de champ RF, les utilisateurs peuvent sur l'exposition aux radiofréquences et la conformité and compliance d'acquérir les informations correspondantes.

Caution

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

The symbol indicates DC voltage

RECYCLING

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment. User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.


This product can be used across EU member states. The device is low power device, it can meet the requirement of the RF exposure.

Notes:

- High Sound Pressure
- Hearing Damage Risk
- Do not listen at high volume levels for long periods.

Made in China

V30



V30 User Manual


Open Ear Headphones

V2.1 2025.04.21

In the Box



Charging Case * 1



Type-C Cable * 1



Earbud * 2



User Guide * 1





Note: Please remove the insulating film from the earbuds prior to their first use.

Specifications

Model No.	V30
Input	5V $\overline{\text{---}}$ 0.5A
Battery Capacity	3.7V 400mAh, 1.48Wh
FCC ID	2BCVF-SY100
Transmission Range	10m/33feet
Driver Size	Φ 11*15mm
Impedance	16 Ω /20mW

Product Introduction






First Use

Before the first use, please tear off the isolating film on the earbuds. Put the earbuds into the case, then charge both earbuds and charging case via supplied Type-C charging cable for at least 10mins (or after not use for a long time), do not take out the earbuds during this period.



Wearing


1. Position the earbuds just above your ears, with the ear hooks facing downward.
2. Gently rotate the ear hooks downward, following the contour of your outer ear auricle until they are securely positioned.
3. Complete insertion.




Power On/Off

Power on

1. Pick up buds from the charging case.



2. Tap and hold for 2s(* Each bud needs to be powered on separately.)





Power off

1. Put back into the charging case

2. Not connected to any devices over 5mins

3. Non-connected, tap and hold for 5s any buds (* Earbuds will be powered off simultaneously.)



Control



Music Control

- Play/Pause**
Double-tap(R/L)
- Next Track**
Triple-tap(R)
- Previous Track**
Triple-tap(L)
- Volume +**
Tap and hold(R)
- Volume -**
Tap and hold(L)

Call Control

- Answer a call**
Double-tap(R/L)
- End a call**
Double-tap(R/L)
- Reject a call**
Tap and hold for 2s(R/L)

Voice Control



- Activate/Stop voice assistant**
Triple-tap(R/L)

Single earbud control

Both earbuds support independent use for mono music or calls. When used alone, the earbuds could not adjust the volume, only switch music to next song.

Bluetooth

After turning them on, search for the Bluetooth device "V30" on your cellphone to connect.



Reset

1. Symptom

When only one side play music.

When you can't find "V30" on your device.


Occur connection issues.

2. Solution

1. Delete all "V30" on your phone and deactivate the Bluetooth setting.
2. Quick click both earbuds 5 times simultaneously, their LED will flash red and blue light at the same time for 3 times to indicate that both earbuds are fully reset.
3. Then put the earbuds in the charging case and charge them for a while. Now, pick up the earbuds to turn them on, activate the Bluetooth setting on your device and select "V30" to connect, it should work

properly.


If not, please put the earbuds back to the charging case and repeat the steps above.



Charging

Charging case battery status

- ★ When the battery level is 21%-100%, the blue light will last 10 seconds then switch off.
- ★ When the battery level is 0%-20%, the red light flashes rapidly for 10 seconds.




When charging the case, the indicator light on the charging case will display the current battery level. After that, it will slowly flash blue. Once fully charged, the light will stay on for 10 seconds before turning off.

How to Check the Battery Level of the Charging Case?

When you place the earbuds into the charging case or when the charging case is being charged, please refer to the charging case's battery status.

Earbuds charging status

The earbud's red light will flash slowly and turn off when fully charged. The charging case's indicator light will turn off after displaying the battery status.



How to sync volume on Android?


For some Android phones, you may need to enable the 'Bluetooth earphone volume sync' or 'absolute volume' option on your phone to achieve the best volume experience. The settings may vary by brand.

Maintenance


- ① Please remove the protective film before use, otherwise the earbuds will not be able to charge.
- ② Please clean the protective grille of both earbuds if the sound becomes low.
- ③ If the earbuds can't be charged, please clean the magnet charging contacts on the earbuds and the charging pins on the case with alcohol wipes.




Tear off the protective film



Protective Grille



Charging Pins



Charging Contacts



Safety Precautions

1. Please prevent the device from being stricken, dropped, warped, soaked etc.
2. Please do not dismantle the earbuds or charging case.
3. Please stop using the device if it causes any discomfort or pain.
4. Use DC 5V-1A chargers/adapters certified by a regulated manufacturer.



Battery Warning

Using the wrong battery can cause fire and other hazards (for example, in the case of some lithium battery types)

1. Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
2. Do not leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.
3. A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.



FCC Caution

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

 **ISED Warning**

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device is compliance with RF exposure guidelines, users can obtain Canadian information on RF exposure and compliance.

Le présent appareil est conforme

Après examen de ce matériel aux conformité ou aux limites d'intensité de champ RF, les utilisateurs peuvent sur l'exposition aux radiofréquences et la conformité and compliance d'acquérir les informations correspondantes.

 **Caution**

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

 The symbol indicates DC voltage




RECYCLING

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European

directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment. User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.

This product can be used across EU member states.

The device is low power device, it can meet the requirement of the RF exposure.

Notes: 

1. High Sound Pressure
2. Hearing Damage Risk
3. Do not listen at high volume levels for long periods.

  
Made in China