



## FREQUENTLY ASKED QUESTIONS

### Where is my Windows Product key sticker?

For most systems the Windows Product Key sticker is located on the side of your PC. For some systems, it may be placed on the back. **Some systems do not require a product key to be entered for activation, and are pre-activated by iBUYPOWER.** During your first boot experience, Windows will ask for your product key if it is required.

### Why did my computer come with extra cables and extra discs?

All extra accessories are supplied in the event that you would like to add more devices or peripherals to your computer. Extra discs are provided to assist with reinstalling Windows and/or the necessary drivers. These should only need to be used when reformatting your system, as all necessary drivers will have been installed during assembly.

### I can hear my system boot up, but the screen is blank.

This may be caused by your monitor being plugged into the wrong video port. The monitor should be connected to the video card (horizontal port underneath the audio ports) as opposed to the motherboard (vertical port near the top of the PC). Also, be sure that your monitor is set to the correct input (HDMI, DVI, etc.).

### When I start the computer, I see "No Boot Device Found."

Check that all cables are properly connected as they may have come loose during shipping. If all cables are properly connected and the problem persists, your computer may be trying to boot to the wrong disk drive.

Contact our **tech support at 888-618-6040** or online at [www.ibuypower.com/Support](http://www.ibuypower.com/Support)

for further assistance.



## CUSTOMER SERVICE HOURS:

MON - FRI: 8:30AM - 5:30PM PST

TOLL FREE: (888) 462-3899

PHONE: (626) 269-5200

## TECHNICAL SUPPORT HOURS:

MON - FRI: 8:30AM - 5:00PM PST

TOLL FREE: (888) 618-6040

PHONE: (626) 269-5170

## IBUYPOWER

[WWW.IBUYPOWER.COM](http://WWW.IBUYPOWER.COM)

529 N. BALDWIN PARK BLVD

CITY OF INDUSTRY, CALIFORNIA 91746

# QUICK START GUIDE

## READ THIS FIRST




**iBUYPOWER**

# QUICK START GUIDE


## HELLO DREAM PC!

## REMOVING PROTECTIVE FOAM

Before you begin, you **must remove** the protective packing foam before turning on your system.




Note: Some cases may have plastic film on the side panel. You can remove these.



Carefully and gently remove the protective packing foam from inside the system

Unscrew the screws from the left side panel and remove the panel



Note: Depending on system build, there may be more cables.

Check that the cables were not disconnected during shipping

## CONNECT

### CONNECTIVITY 101

Connect your display, peripherals, and more, for the ultimate gaming experience.



Note: Different video cards have different connectivities

Connect your display only to the video card installed as shown

### DISPLAY AND PERIPHERALS

#### Connection Types

- VGA
- DVI - Single Link
- DVI - Double Link
- HDMI
- Display Port
- Mini Display Port

Note: Ports may vary depending on your motherboard



Mic Audio

USB 2.0 USB 3.0




Connect your peripherals shown on the diagram above

## POWER


### LET THERE BE LIGHT!

### POWER ON YOUR PC

Connect the power cable to the back of your system. Make sure the power supply is switched on.



Plug-in the power cord and switch on the power supply before hitting the power button





Power on the system by pressing the power button (location of button may vary)

## ACTIVATE

### ALMOST THERE!

### ACTIVATING WINDOWS PRODUCT KEY



Note: In some instances, your system is pre-activated by iBUYPOWER and will not require a product key to be entered

Find the Windows Product Key sticker on the side or back of your computer and copy the code exactly. We recommend taking a picture. (Some systems may not require this step)