


Please read the following before use. Clean the surface of the table before use. Dust or other obstacles may affect the performance of the vehicle.

How to remove the rear wheels

When you want to remove the dust from the shaft, remove the rear wheels before cleaning.


1 Take out the rear wheels. (Be careful not to bend the shaft while removing.)



After cleaning, re-install the rear wheels.


If the front wheel becomes detached from the vehicle

If the front wheel is detached, install in the sequence as shown in the diagram.



Battery removal and installation instructions

- Open the battery door with a screwdriver.
- If used batteries are present, remove these batteries from the unit by pulling up on one end of each battery.
- Install new batteries as shown in the polarity diagram (+/-) inside the battery compartment.
- Replace battery door securely.
- Check your local laws and regulations for correct recycling and/or battery disposal.



How to recharge

- Open the cover as shown. Uncover the charging plug.
- Turn ON/OFF switch on the car to OFF. Turn ON/OFF switch on controller to ON. Insert the charging plug into the charging socket on the car. The LED display will illuminate and charging will begin. (Green Light)
- Charging will be done in 5 minutes and the indicator will go off accordingly. Then you can pull out the charging plug from the car.



Due to the properties of the internal battery, the battery may not be fully charged and may experience shorter operation time when using for the first time or if left unoperated for a long period of time. In this case, charge and operate car 4-5 times. Doing so will extend battery life.

Charge battery only after Windstorm Trucks unit is no longer in motion. DO NOT charge Windstorm Trucks unit when fully charged. This will not affect the car's running speed.

Allow the Windstorm Trucks unit a short break if it becomes warm.

How to play

- OFF/ON switch
- Move ON/OFF switch to the ON position as shown. The flashing light in the car will light up, indicating the car has entered standby state. Turn OFF the Windstorm Trucks vehicle when not in use to preserve batteries. Move ON/OFF switch to the OFF position.




- Controls
 - Throttle buttons
 - Direction button
- The throttle button on the left controls the vehicle's forward and backward direction.
- The direction button on the right controls the direction of vehicle's front wheels.
- Press the throttle and direction button together to achieve right forward, left forward, right backward and left backward movements.

- Turbo button
- Press the turbo button to switch between high and low speed modes.
- Long press the turbo button to enter the automatic demonstration modes.

- ### How to adjust the car to go straight ahead
- Adjust to left / Adjust to right
- Trim switch
- Bottom View
- When the Windstorm Trucks vehicle does not travel in a straight line, adjust the trim switch inside the truck.
- ### Features
- Rear Suspension
- Front Suspension
- Turn On/Off switch on controller to On. The red indicator light will flash until the car is connected.
- Suspensions are equipped on the front and rear parts of the Windstorm Trucks vehicle.

Recycle the nickel metal hydride (NiMH) battery

Your Windstorm Trucks vehicle contains a nickel metal hydride battery. After recharging and using your Windstorm Truck approximately 500 times, the nickel metal hydride battery cannot be charged again. Properly recycle the ENTIRE Windstorm Trucks vehicle.



NOTE: Nickel metal hydride battery can be used approximately 500 times (recharge and use).

Troubleshooting

PROBLEM	CAUSE	SOLUTION
Vehicle does not move	The controller/charger was not pointed towards the Windstorm Trucks.	Transmission is weakened due to low battery level. Point the controller/charger directly at the Windstorm Trucks.
	The power of the Windstorm Trucks or controller/charger was running out.	Recharge the Windstorm Trucks. If the problem continues charge the batteries in the controller/charger.
	The band of the controller/charger did not match with the Windstorm Trucks vehicle.	Adjust the controller/charger to the same band as the the Windstorm Trucks.
	2.4 G signals could not reach the Windstorm Trucks because the distance was too far or the angle was wrong.	Close the distance between the the Windstorm Trucks and the controller/charger. 2.4 G signals can reach up to 30 feet (10 metres).
	Obstacles appeared between the Windstorm Trucks and controller/charger.	Remove the obstacle and close the distance between the Windstorm Trucks and the controller/charger.
Unable to control properly	The shaft of rear wheel was detached from the chassis.	Reinstall the rear wheel to the chassis.
	Dust or rubbish attached to the tires or the gear.	Take out the rear wheel and clean the dust or rubbish.
	Playing on carpet or wool cloth surface.	Play on smooth surface like wooden floor.
	Trim switch not properly adjusted.	Move the trim switch until the vehicle drives in a straight line.
	Battery is low, causing intermittent movement.	Recharge the the Windstorm Trucks. If the problem continues, change the batteries in the controller/charger.

NOTE: If normal function of the product is disturbed or interrupted, strong electro-magnetic interference may be causing the issue. To reset product, turn it completely off, then turn it back on. If normal operation does not resume, move the product to another location and try again. To ensure normal performance, change the batteries, as low batteries may not allow full function.

Your Windstorm Trucks vehicle is equipped with a rechargeable nickel metal hydride (NiMH) battery.

SPECIAL NiMH BATTERY INSTRUCTIONS:

- Never charge battery unattended.
- Charge battery in isolated area. Keep away from flammable materials.
- Do not expose to direct sunlight.
- There is a risk of the batteries exploding, overheating, or igniting. Do not disassemble, modify heat, or short circuit the batteries. Do not place them in fires or leave them in hot places.
- Do not drop or subject to strong impacts.
- Do not allow the batteries to get wet.
- Only charge the batteries with the specified Spin Master battery charger.
- Only use the batteries in the device specified by Spin Master.
- Carefully read the instruction guide, and use the batteries correctly.
- In the unlikely event of leakage or explosion use sand or a chemical fire extinguisher for the battery.
- Batteries must be recycled or disposed of properly.

BATTERY SAFETY INFORMATION:

- Requires 3 x 1.5V AAA alkaline batteries (not included).
- Batteries are small objects.
- Replacement of batteries must be done by adults.
- Follow the polarity (+/-) diagram in the battery compartment.
- Promptly remove dead batteries from the toy.
- Dispose of used batteries properly.
- Remove batteries for prolonged storages.
- DO NOT incinerate used batteries.
- DO NOT dispose of batteries in fire, as batteries may explode or leak.
- DO NOT mix old and new batteries or types of batteries (i.e. alkaline/standard).
- DO NOT use rechargeable batteries.
- DO NOT recharge non-rechargeable batteries.
- DO NOT short-circuit the supply terminals.

Contains nickel metal hydride battery pack. Battery pack must be recycled or disposed of properly.

FCC Statement
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

8+ years

WINDSTORM TRUCKS

INSTRUCTION GUIDE

- CAUTION: Windstorm Trucks contain a magnet. Do not place near objects that could be affected by magnets, such as cards with a magnetic strip or electronics and medical devices.
- Read the instructions carefully before use
- Discard the tray and plastic packaging immediately after opening.
 - Delicate precision electronic parts are used in this product.
 - Do not drop, immerse in water, soil or disassemble.
 - Avoid storing or using in extreme hot or cold locations.
 - Bright sunlight or certain fluorescent lighting can interfere with the controller/charger's infrared signal.
 - Objects between the line-of-sight of the controller/charger and the Thunder Trucks vehicle may interfere with the signal.
 - Please be aware that in rare cases other IR devices such as TV remote controllers may interfere with Micro Terrain Titans and the Windstorm Trucks controller/charger may interfere with other such devices.
 - Performance may be limited on some surfaces such as thick or shag carpeting.

NOTE: These instructions apply to all types of Windstorm Trucks vehicles. Different models have different tires and body.

Getting to know your Windstorm Trucks vehicle

- Contents:
- 1 Windstorm Trucks
 - 1 Controller/Charger
 - 1 Instruction Guide

