


amazonbasics



Mini Guitar Amplifier - 3 Watt, 2 Channels

Mini-Amplificateur de Guitare - 3 Watts, 2 Canaux

Miniamplificador de Guitarra - 3 Watts, 2 Canales

B0825LBTNM

English	3
Français	14
Español	24

IMPORTANT SAFETY INSTRUCTIONS



Read these instructions carefully and retain them for future use. If this product is passed to a third party, then these instructions must be included.

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons including the following:

⚠ WARNING Risk of fire or electric shock!

To reduce the risk of fire or electric shock, do not expose this product to rain or moisture.

- Read these instructions.
- Keep these instructions.
- Heed all instructions.
- Do not use the product near water.
- Clean only with dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not use near any heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.

- Radios and TVs placed nearby may experience reception interference. Operate this product at a suitable distance from radios and TVs.
- Only use attachments/accessories specified by the manufacturer.
- Refer all servicing to qualified service personnel. Servicing is required when the product has been damaged in any way, liquid has been spilled or objects have fallen into the product, the product has been exposed to rain or moisture, does not operate normally or has been dropped.



To prevent possible hearing damage, do not listen at high volume levels for long periods. As a guide to setting the volume level, check that you can still hear your own voice when speaking normally while listening with headphones.

Battery Warnings

NOTICE The batteries are not included.


- Always insert batteries correctly with regards to polarity (+ and -) marked on the battery and the product.
- Exhausted batteries should be immediately removed from product and properly disposed.

Symbols Explanation

 Direct current (DC)

 Plug polarity


Intended Use

- This product can be powered by a power adapter with 9 V  output, USB power bank or by 6 AA batteries.
- This product is intended for private use only. It is not intended for commercial use.
- This product is intended to be used in dry indoor areas only.
- No liability will be accepted for damages resulting from improper use or non-compliance with these instructions.





Product Description



- | | |
|---------------------------|--------------------------|
| A INPUT jack | H Indicator light |
| B CLN/DST button | I USB socket |
| C GAIN knob | J DC socket |
| D VOLUME knob | K POWER button |
| E TONE knob | L AUX IN jack |
| F DELAY TIME knob | M PHONES jack |
| G DELAY LEVEL knob | |



Before First Use

- Check the product for transport damages.
- Remove all the packing materials.


⚠ DANGER Risk of suffocation! Keep any packaging materials away from children – these materials are a potential source of danger, e.g. suffocation.



Operation

Inserting batteries

1. Open the battery compartment on the backside of the product.
2. Insert 6 batteries (type AA).
3. Close the battery compartment.



NOTICE Only use Alkaline batteries (LR6, 15A).

NOTICE Always insert batteries correctly with regard to polarity (+ and -) marked on the battery and the product.

Connecting to power supply

4. Adapter 9 V --- (not provided):
 - Connect the adapter to the DC socket (J) on the backside of the product.
 - Connect the adapter to a suitable socket-outlet.

5. USB power bank (not provided):
 - Connect a USB cable (not provided) to the USB socket (I) on the backside of the product.
 - Connect the USB cable to a fully charged power bank.

Switching on/off

1. Connect the instrument to the product before switching it on.
2. Set the volume controls of the product and the connected instrument to “0”.
3. Press the **POWER** button (K) to switch the product on/off.
4. The indicator light (H) switches on/off accordingly.
5. Slowly raise the volume controls to the desired level.

Selecting sound mode channel

Press the **CLN/DIST** button (B), to switch between the clean (CLN) and the distortion (DIST) sound mode channel.

Adjusting sound

Knob	Adjustment by turning
GAIN (C)	Set level of gain in the signal. For clean sounds set less gain, for more distorted sounds set more gain.
VOLUME (D)	Set output volume level
tone (E)	Set the overall EQ of the signal.
DELAY TIME (F)	Set delay effect repetition interval.
DELAY LEVEL (G)	Set delay effect level.

Connections

Name	Connection type
INPUT (A)	1/4" (6.35 mm) instrument input
AUX IN (L)	1/8" (3.5 mm) audio input
PHONES (M)	1/8" (3.5 mm) headphones output

Cleaning and Maintenance

NOTICE Switch the product off and disconnect all the connected devices before cleaning.

NOTICE During cleaning do not immerse the product in water or other liquids. Never hold the product under running water.



Cleaning

- To clean the product, wipe with a soft, dry cloth.
- Never use corrosive detergents, wire brushes, abrasive scourers, metal or sharp utensils to clean the product.

Storage

- Store the product in its original packaging in a dry area. Keep away from children and pets.



FCC – Supplier's Declaration of Conformity

Unique Identifier	B0825LBTNM - Mini Guitar Amplifier - 3 Watt, 2 Channels
Responsible Party	Amazon.com Services, Inc
U.S. Contact Information	410 Terry Ave N. Seattle, WA 98109, United States
Telephone Number	(206) 266-1000

FCC Compliance Statement

1. This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:
 - (1) this device may not cause harmful interference, and

- (2) this device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

Canada IC Notice

- This Class B digital apparatus complies with Canadian CAN ICES-3(B) / NMB-3(B) standard.



Battery Disposal



Do not dispose of used batteries with your household waste. Take them to an appropriate disposal/collection site.



Specifications

Power supply:	9 V (power adapter) 6 x 1.5 V (AA battery) 5 V (via USB port)
Frequency response:	40 Hz - 16 KHz
Speaker size:	3"
Rated current:	135 mA
Rated power:	4.2 W
Speaker impedance:	4 Ω
INPUT impedance:	1 M Ω
AUX impedance:	10 K Ω

Signal-to-noise ratio:	88 dB
Net weight:	approx. 2 lbs (0.9 kg)
Dimensions (W x H x D):	approx. 6 x 4 x 7" (15.2 x 10.1 x 17.8 cm)

Feedback and Help

Love it? Hate it? Let us know with a customer review.

AmazonBasics is committed to delivering customer-driven products that live up to your high standards. We encourage you to write a review sharing your experiences with the product.



**[amazon.com/review/
review-your-purchases#](https://amazon.com/review/review-your-purchases#)**



**[amazon.com/gp/help/customer/
contact-us](https://amazon.com/gp/help/customer/contact-us)**



amazonbasics

amazon.com/AmazonBasics

MADE IN CHINA
FABRIQUÉ EN CHINE
HECHO EN CHINA

V01-03/20