


At a glance

Cockpit



1. Steering wheel gearshift paddles
2. Combination switch
3. Instrument Display
4. DIRECT SELECT lever
5. Start/stop button
ECO start/stop function
6. Media display
7. Climate control systems
8. Hazard warning lights
9. PASSENGER AIR BAG indicator lamp
10. Glove box
11. Stowage compartment
12. Cup holder
13. Control knob for:
Volume and switching sound on/off
Switches the MBUX multimedia system on/off
14. Calls up navigation




15. Calls up the radio
Calls up media
16. Calls up the telephone
17. AMG exhaust system
18. AMG adaptive sport suspension system
19. ESP®
20. Manual gearshifting
21. Calls up favorites
22. Calls up vehicle functions
23. Active Parking Assist
24. DYNAMIC SELECT switch
25. Touchpad
26. Control panel for the MBUX multimedia system
27. AMG steering-wheel buttons
28. Adjusts the steering wheel
29. Control panel:
On-board computer
Cruise control
Active Distance Assist DISTRONIC
30. Diagnostics connection
31. Opens the hood
32. Electric parking brake
33. Light switch

Instrument Display and on-board computer




Notes on the Instrument Display and onboard computer

Additional notes regarding your Mercedes-AMG vehicle:

- If you activate manual gearshifting, (page 14) the upshift bar will appear on the

multifunction or Head-up Display. In addition, transmission set-up  (manual) and the current gear will appear on the transmission position display of the multifunction display.

- Additional note regarding the indicator and warning lamps: the vehicle is also equipped

with the ESP® , ESP® OFF  and ESP® SPORT  indicator and warning lamps (page 40).

You can select the following display content:

- Tachometer with gear display
- Date and time
- Warm-up
- AMG TRACK PACE
- G-meter
- Engine data SETUP
- Trip computer
- Navigation
- Media
- Telephone

AMG TRACK PACE is displayed on the left-hand section of the display. The warm-up, engine data, SETUP and G-meter menus are displayed on the right-hand section of the display.

Calling up displays on the Performance menu

On-board computer: Performance

To select a display: swipe upwards or downwards on the left-hand Touch Control.

Displays on the Performance menu:


- Warm-up
- Engine data
- SETUP
- G-meter



Warm-up (example)

1. Digital speedometer
2. Engine oil temperature
3. Transmission oil temperature
4. Boost pressure

If the engine or transmission is not at normal operating temperature, the multifunction display will show temperature **2** or **3** in blue. Avoid using the full engine power output during this time.



Engine data (example)

1. Current power output
2. Current torque

When current power output **1** or current torque **2** reaches the maximum value, the digital value will briefly be stationary. The bar display will continue.



SETUP in Mercedes-AMG vehicles (example)

1. Drive system setting:
Reduced/Moderate/Sport/Dynamic
2. Transmission position:
D/M



3. AMG DYNAMICS:
Basic/Advanced/Pro/Master
4. Suspension tuning:
Comfort/Sport/Sport+
5. Exhaust system:
Balanced/Powerful



G-meter (example)

While the vehicle is in motion, the G-meter shows the forces that are exerted on the vehicle occupants both laterally and in the direction of travel. The maximum values are represented by red markings.


- **To reset the G-meter:** press the left-hand Touch Control.
- Select Yes.
- Press the left-hand Touch Control.

Function of the Head-up Display

The Head-up Display projects information above the cockpit into the driver's field of vision, e.g. the speed of the vehicle, information from the navigation system or driver assistance systems and some warning messages.

Depending on the vehicle's equipment, different content can be shown in the three areas of the Head-up Display.

Mercedes-AMG display content



1. Protection from reaching the overrevving range
2. Detected instructions and traffic signs
3. Current speed
4. Currently selected gear, gearshift options with manual shifting
5. Current engine speed

Depending on the vehicle's equipment, you can select further AMG displays in addition to the standard displays on the Display Content menu.

In vehicles with AMG TRACK PACE, you can display additional content:

- Speed and gear display
- Lap and sector times
- Acceleration and braking
- Track layout graphics

Important: The content that can be displayed will vary depending on the settings.



When you receive a call, the Incoming Call message will appear on the Head-up Display.

In audio mode, the station name or track will be shown temporarily when the audio source is being actively operated.

System limits

The visibility of the displays will be affected by the following conditions:

- Seat position

- Image position setting
- Ambient light
- Wet roadway
- Objects on the display cover
- Polarization in sunglasses

Important: In extreme sunlight, sections of the display may appear washed out. You can correct this by deactivating and reactivating the Head-up Display.

Wheels and tires

Overview of the tire-change tool kit


Apart from some country-specific variants, vehicles are not equipped with a tire-change tool kit. For more information on which tire-changing tools are required and approved for performing a wheel change on your vehicle, consult a qualified specialist workshop.

Required tire-change tools may include, for example:

- Jack
- Chock
- Lug wrench
- Alignment bolt

The tire-change tool kit is in a well in the stowage space under the trunk floor.

Setting up the folding chock




Changing a wheel

Be sure to also observe the notes on changing a wheel in the Operator's Manual of your vehicle.

Installing/removing plastic hub caps

Removing



- Remove socket **2** and lug wrench **3** from the vehicle tool kit (page 33).
- Position socket **2** on hub cap **1**.
- Position wheel wrench **3** on socket **2**.
- Using wheel wrench **3**, turn hub cap **1** counter-clockwise and remove it.

Installing


- Before installing, check hub cap **1** and the wheel area for dirt, and clean if necessary.
- Position hub cap **1** and turn until it is in the right position.
- Position socket **2** on hub cap **2**.
- Position lug wrench **3** on socket **2** and tighten hub cap **2**.

Specified tightening torque: 18 lb-ft (25 Nm).

Display messages and warning/indicator lamps




Display messages

Driving systems

Display messages	Possible causes/consequences and Solutions
RACE START Not Possible See Operator's Manual	* Possible causes are: <ul style="list-style-type: none"> • The conditions for activation are not met (page 19).
RACE START Canceled	* Possible causes are: <ul style="list-style-type: none"> • you released the accelerator pedal during RACE START. • you depressed the brake pedal during RACE START. You can try RACE START again at the next start.
DRIFT MODE Currently Unavailable See Operator's Manual	* Possible causes: <ul style="list-style-type: none"> • The activation conditions have not been fulfilled (page 21).
 <p>Malfunction Drive at Max. 50 mph</p>	* The AMG adaptive sport suspension system is malfunctioning. The vehicle's handling characteristics may be affected. <ul style="list-style-type: none"> • Do not drive at speeds greater than 50 mph (80 km/h). • Consult a qualified specialist workshop


Warning and indicator lamps

Driving safety systems

Warning/indicator lamp	Possible causes/consequences and Solutions
 <p>ESP® OFF warning lamp</p>	<p>The yellow ESP® OFF warning lamp is lit while the engine is running. *ESP® is deactivated.</p> <p>WARNING - Risk of skidding when driving with ESP® deactivated</p> <ul style="list-style-type: none"> • If ESP® is deactivated, ESP® cannot carry out vehicle stabilization. The availability of further driving safety systems is also limited. <ul style="list-style-type: none"> ◦ Drive on carefully. ◦ Only deactivate ESP® for as long as the situation requires. • If ESP® cannot be activated, ESP® is malfunctioning. <ul style="list-style-type: none"> ◦ Have ESP® checked immediately at a qualified specialist workshop. <p>Observe the notes on deactivating ESP® (page 16).</p>
 <p>ESP®SPORT warning lamp</p>	<p>ESP® SPORT is activated while the engine is running. *When ESP® SPORT is activated, ESP® will stabilize the vehicle only to a limited extent.</p> <p>WARNING - Risk of skidding if ESP® SPORT is used incorrectly</p> <ul style="list-style-type: none"> • When you activate ESP® SPORT, there is an increased risk of skidding and having an accident. <ul style="list-style-type: none"> ◦ Activate ESP® SPORT only in the circumstances described below. <p>Observe the notes on activating ESP®SPORT (/ page 16)</p>
 <p>DRIFT warning lamp</p>	<p>DRIFT MODE is activated while the engine is running.</p> <p>WARNING - Risk of skidding and having an accident from wheels spinning</p> <p>When you use DRIFT MODE, ESP® is not available. Individual wheels could spin and you could lose control of the vehicle. There is an increased risk of skidding and having an accident.</p> <ul style="list-style-type: none"> • Do not use DRIFT MODE on normal roads. • DRIFT MODE may only be activated and used on closed race circuits, not on public roads.

Warning/indicator lamp	Possible causes/consequences and Solutions
	<ul style="list-style-type: none"> • Make sure that no persons or obstacles are in the close vicinity of your vehicle. <p>Observe the notes on activating DRIFT MODE (page 20).</p>

Driving systems

Warning/indicator lamp	Possible causes/consequences and Solutions
 <p data-bbox="172 925 451 1003">Suspension warning lamp</p>	<p>The yellow AMG adaptive sport suspension system warning lamp is lit.</p> <p>* There is a malfunction in the AMG adaptive sport suspension system.</p> <p>Note the messages on the multifunction display.</p>

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.