

## Overview

The Brita UltraMax is a large-capacity, freestanding water dispenser designed to filter tap water. It is BPA-free and uses a replaceable filter to reduce specific impurities.



### Key Components:

- Water Dispenser Reservoir
- Lid with Locking Mechanism
- Precision-Pour Spigot
- Filter Housing
- One Standard Brita Filter (included)
- Filter Change Indicator Sticker


# Features and Specifications

## Physical Specifications

- **Brand:** Brita
- **Model Name:** UltraMax
- **Model Number:** OB24/OB06
- **Capacity:** 27 Cups (Approx. 13.5 Pounds / 6.4 Liters)
- **Product Dimensions:** 18" L x 5.67" W x 10.47" H
- **Item Weight:** 3 Pounds
- **Material:** BPA-Free Plastic
- **Installation Type:** Freestanding
- **Special Feature:** Change Filter Indicator

## Filtration Specifications

- **Purification Method:** Carbon Block with Ion Exchange Resin
- **Filter Compatibility:** Brita Standard and Brita Elite Filters
- **Standard Filter Life:** 40 Gallons or approximately 2 months.
- **Elite Filter Life:** 120 Gallons or approximately 6 months.
- **Reduces:** The taste and odor of chlorine. Also reduces copper, cadmium, and mercury impurities as per manufacturer specifications.
- **Supported Water TDS Level Maximum:** 1500 PPM



# Setup and Use Guide

## Initial Setup

1. **Unpack:** Remove the dispenser and the included Standard filter from the packaging.
2. **Prepare the Filter:**
  - Remove the filter from its packaging.
  - Soak the filter in cold water for 15 minutes.
  - Rinse under cold running water for 15 seconds.
3. **Install the Filter:**
  - Open the lid of the dispenser.
  - Insert the prepared filter into the filter housing at the top of the reservoir. Push down firmly until it clicks into place.
4. **Fill and Prime:**
  - Fill the reservoir with cold tap water.
  - Close the lid securely.
  - Dispense and discard the first three full containers of water to prime the filter and remove carbon dust. This water is not for drinking.
5. **Set Filter Indicator:** Attach the included filter change indicator sticker to the dispenser or fridge and set the date for 2 months from now.

## Daily Use

1. Open the lid and fill the reservoir with cold tap water.
2. Close the lid until it locks. The easy-locking lid helps prevent spills.
3. Place the dispenser on a flat, stable surface, such as a kitchen countertop or inside a refrigerator shelf.
4. To dispense water, place a cup or container under the spigot and press the lever on the precision-pour spigot.

# Smart Filtration

Brita Original™ keeps in minerals that ZeroWater removes\*



\*Brita Original™ does not remove lead. See performance data sheet on Brita website for details. Substances reduced may not be in all users' water. Minerals may not be present in all users' water.

## Filter Replacement

Replace the filter when the indicator shows it's time (every 40 gallons/2 months for Standard, 120 gallons/6 months for Elite), or if water flow slows significantly.

1. Lift the lid and remove the old filter by pulling it straight up from the housing.
2. Prepare a new Brita Standard or Elite filter by soaking and rinsing it as described in the Initial Setup.
3. Insert the new filter into the housing until it clicks into place.
4. Prime the new filter by dispensing and discarding the first three containers of water.
5. Reset your filter change indicator sticker to the new replacement date.

# Longer Filter Life

Brita Original™ is certified to last over 2x longer than ZeroWater.\*



\*Brita Original™ does not remove lead. Based on certified filter life for Brita Original™ (40 gallons) vs. ZeroWater 5-stage (15 gallons) and average household usage of 11 cups per day.

## Cleaning and Maintenance

### Regular Cleaning

- Wipe the exterior of the dispenser with a soft, damp cloth. Do not use abrasive cleaners.

- Regularly clean the lid and spigot area to prevent buildup.

## Deep Cleaning the Reservoir

1. Remove the filter and set it aside.
2. Wash the reservoir with mild dish soap and warm water. Use a soft bottle brush if needed.
3. Rinse thoroughly to remove all soap residue.
4. Reinstall the filter and prime with water as described in the Initial Setup.

## Troubleshooting

- **Water is not dispensing / Slow flow:** Check that the filter is properly installed and not expired. A clogged, old filter is the most common cause.
- **Water tastes unusual:** Ensure you have primed a new filter correctly. Confirm the filter has not exceeded its recommended lifespan.
- **Lid is difficult to close:** Ensure the filter is fully seated and not obstructing the lid.
- **Leaking from spigot:** Ensure the spigot lever is fully returning to the closed position. Check for debris obstructing the seal.

## Safety and Compliance

- Use only with cold tap water. Do not use with hot water.
- Use only genuine Brita Standard (OB03) or Elite (OB06) filters. The use of non-Brita filters is not recommended.
- Do not place near heat sources or in direct sunlight.
- Keep out of reach of small children.
- For compliance information, refer to the Certificate of Compliance available from the manufacturer.



**Choose Brita.™**  
For Contaminant  
Reduction\*

NSF/ANSI Certified Contaminants*	Brita Original	Brita Plus	Amazon Basics	Aqua Crest	Pure line	Water Drop
Model	(OB03)	(OB08)	(1038346)	(AQK-CF06A)	(PL-3700-S)	(WD-C06)
Copper	●	●	●			
Cadmium	●	●				
Mercury	●	●	●			
Zinc	●	●				
Chlorine	●	●	●	●	●	●
Benzene		●	●			
Ethylbenzene		●				
Tetrachloroethylene		●				
Toluene		●				
1,2,4-Trichlorobenzene		●				

\*Based on information listed on WQA & NSF as of 7/30/24

## What's in the Box

- Brita UltraMax Water Dispenser (27-Cup Capacity)
- One Brita Standard Water Filter

### Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.