

## Overview

The JOYWISE U8 Pro are wireless in-ear headphones designed for active use. They feature Bluetooth 5.3 connectivity, an IPX7 waterproof rating, and up to 16 hours of playtime.




## Features

### Sound and Audio


- **Sound Isolation Technology:** Built-in chip helps block external noise for immersive listening.

- **Stereo Surround Sound:** Features an 11mm dynamic driver for spatial audio with powerful bass, mellow mid-range, and clear treble.
- **Built-in Microphone:** For hands-free calls with voice notification for incoming calls.



## Battery and Charging

- **Up to 16 Hours Playtime:** Provides extended use on a single charge.
- **Fast Charging:** Approximately 1.5 hours to fully charge the headphones.
- **Standby Time:** Up to 250 hours in standby mode.
- **Battery Status Display:** The battery level is displayed on the connected device.



## Design and Durability

- **IPX7 Waterproof:** Protected against sweat and rain using a sealed shell and nano-coating. Not for swimming.
- **Secure and Comfortable Fit:** Hook-shaped earpiece design is intended to fit securely in the ear during physical activity.



## Connectivity and Controls

- **Bluetooth 5.3:** For a stable wireless connection.
- **Dual Connection:** Can be connected to two devices simultaneously.
- **Wireless Range:** Up to 30 feet in open space; approximately 10 feet with obstacles.
- **Physical Button Control:** Buttons on the earbuds allow for play/pause, track skipping, and call management without using your phone.
- **Note:** These headphones cannot connect to smartwatches.



## Use Guide

### Charging the Headphones

1. Connect the provided USB cable to the charging port on the headphone case.
2. Plug the other end into a USB power adapter or computer port.
3. A full charge takes approximately 1.5 hours.

### Powering On/Off and Pairing

1. Remove the earbuds from the charging case. They will power on automatically.
2. On your Bluetooth-enabled device (e.g., phone, laptop, tablet), enable Bluetooth in the settings.
3. Search for available devices and select "JOYWISE U8 Pro" from the list.
4. If prompted, confirm the pairing. A voice prompt may indicate a successful connection.
5. To power off, place the earbuds back into the charging case.

### Using the Controls

The physical buttons on each earbud are used for control. Refer to the specific button layout on your earbuds for the following functions:

- **Play/Pause:** Press the multifunction button once.
- **Answer/End Call:** Press the multifunction button once.
- **Reject Call:** Press and hold the multifunction button.
- **Next Track:** Press the volume up or designated button twice.
- **Previous Track:** Press the volume down or designated button twice.
- **Volume Up/Down:** Press the respective volume buttons.

- **Voice Assistant:** Activate your device's voice assistant (e.g., Siri, Google Assistant) by pressing and holding the multifunction button (function may vary by device).

## Connecting to a Second Device

1. Ensure the headphones are connected to the first device and are in standby mode (audio not playing).
2. On the second device, enable Bluetooth and select "JOYWISE U8 Pro" from the list of available devices.
3. The headphones will manage audio from the most recently active device.

## Product Information

- **Model Name:** U8 Pro
- **Connectivity Technology:** Bluetooth 5.3, Wireless
- **Water Resistance Level:** IPX7 Waterproof
- **Battery Life:** Up to 16 hours
- **Charging Time:** ~1.5 hours
- **Audio Driver:** 11mm Dynamic Driver
- **Bluetooth Range:** Up to 30 ft (open space)
- **Included Components:** Charging Cable
- **Control Method:** Button, Voice
- **Compatible Devices:** Laptops, Cellular Phones, Tablets, MP3 Players, Audio & MIDI Interfaces, Audio CD Players.

## What's in the Box

- JOYWISE U8 Pro Wireless Headphones (with charging case)
- Charging Cable (USB)
- Ear tips (assumed, based on standard product category)
- User Manual (this document)

### Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.

