

1. Safety Information and Warnings

Important Safety Instructions

- **Charging Safety:** Use only the provided Type-C cable. Do not use the vacuum while it is charging.
- **Operational Safety:** Do not use the device to vacuum liquids, hot ashes, or burning objects. Keep away from wet surfaces.
- **Battery Safety:** Do not attempt to disassemble or puncture the battery. Avoid exposure to direct sunlight or high temperatures.
- **Maintenance Safety:** Always turn off and unplug the device before cleaning or replacing filters and accessories.
- **Intended Use:** This vacuum is designed for dry, indoor debris such as dust, crumbs, and pet hair on surfaces like carpets, furniture, and car interiors.

2. Product Overview

What's in the Box

- JONYJ Handheld Vacuum Main Unit × 1
- Type-C Charging Cable × 1
- Accessory Kit:
 - Long Crevice Nozzle
 - Brush Nozzle
 - Flexible Extension Hose
- Stainless Steel Filter × 1
- Washable HEPA Filter × 2
- User Manual × 1

Core Specifications

Feature	Specification
Model	LT-156
Suction Power	16,000 Pa
Motor Speed	72,000 RPM
Battery Capacity	7800 mAh
Runtime	Up to 30 minutes
Charge Time	Approx. 3.5 hours (Type-C)
Dust Cup Capacity	400 ml
Noise Level	≤ 75 dB
Product Weight	Approx. 1.7 lbs (0.77 kg)
Product Dimensions	Approx. 17.4" (L) x 3.9" (W) x 5.5" (H)

Key Parts Identification:

1. Power Button
2. LED Work Light
3. Dust Cup Release Button
4. Suction Intake (for attaching nozzles)
5. Type-C Charging Port
6. Battery & Charge Status Indicator
7. Ergonomic Handle

3. Getting Started

Initial Charging

1. Connect the provided Type-C cable to the vacuum's charging port.
2. Plug the other end into a standard USB power adapter (5V/2A recommended), computer, or power bank.
3. The indicator light will show charging status. A full charge takes about 3.5 hours.
4. It is recommended to fully charge the vacuum before first use.

Assembling for Use

1. **Install Filters:** Ensure the stainless steel filter and the HEPA filter are correctly placed inside the dust cup assembly.
2. **Attach Nozzle:** Choose the desired accessory (crevice tool, brush, or hose) and push it firmly onto the vacuum's suction intake until it clicks into place.
3. **Power On:** Press the power button to start. The built-in LED light at the suction intake will automatically turn on to illuminate dark areas.
4. **Power Off:** Press the power button again to turn the vacuum off.

4. Using Your Vacuum

Selecting the Right Nozzle

Nozzle	Best For	How to Use
Long Crevice Nozzle	Narrow gaps, car seat tracks, window edges, between appliances.	Ideal for directing powerful suction into tight spaces where debris accumulates.
Brush Nozzle	Upholstery, cushions, keyboards, lampshades, pet hair on fabric.	The bristles help loosen and lift embedded dust and hair for effective pickup.
Flexible Extension Hose	Hard-to-reach areas: under furniture, behind shelves, car footwells, overhead corners.	Provides extended reach and flexibility to clean areas without moving heavy objects.

Optimal Cleaning Techniques

- **For Best Suction:** Move the nozzle slowly over the surface, allowing the vacuum to pick up all debris.
- **Using the LED Light:** The light is particularly useful for cleaning under car seats, inside dark cabinets, or in dimly lit corners to ensure no dirt is missed.
- **Regular Emptying:** For maximum efficiency, empty the dust cup when it is about half to two-thirds full. Do not overfill.

5. Maintenance and Care

Emptying the Dust Cup

1. Turn off and disconnect the vacuum from the charger.
2. Press the dust cup release button and detach the cup from the main body.

3. Empty the contents into a trash bin. You may tap it gently to dislodge any stuck particles.
4. Reattach the dust cup by aligning it with the main body and pushing until it clicks securely.

Cleaning the Filters (Recommended Weekly or When Suction Decreases)

1. Remove the dust cup and take out both the stainless steel and HEPA filters.
2. Gently tap the filters over a trash can to remove loose dust.
3. Rinse both filters under lukewarm running water. Do not use soap or chemicals. Gently shake off excess water.
4. **CRUCIAL:** Allow both filters to air dry **completely** for at least 24 hours in a well-ventilated area before reinstalling. Using a damp filter will damage the motor.
5. Once completely dry, reassemble the filters into the dust cup and reattach to the vacuum.

General Care

- Wipe the exterior of the vacuum with a soft, dry cloth.
- Check nozzle openings and the suction path for blockages (like large debris or hair) and clear them if found.
- Store the vacuum and its accessories in a cool, dry place.

6. Troubleshooting

Problem	Possible Cause	Solution
Vacuum won't turn on	Battery is depleted.	Connect to charger and allow it to charge fully.
Weak suction power	<ol style="list-style-type: none">1. Dust cup is full.2. Filters are dirty or wet.3. Nozzle or intake is clogged.	<ol style="list-style-type: none">1. Empty dust cup.2. Clean and thoroughly dry filters.3. Check and clear any blockages.
Vacuum stops during use	<ol style="list-style-type: none">1. Motor overheated.2. Battery is empty.	<ol style="list-style-type: none">1. Turn off and let it cool for 30 minutes.2. Recharge the battery.
LED light not working	Light may be faulty.	The vacuum can still operate. Contact customer service if light is essential.
Battery not charging	<ol style="list-style-type: none">1. Loose cable connection.2. Faulty cable or power source.	<ol style="list-style-type: none">1. Check both ends of the Type-C cable.2. Try a different cable or USB port.

7. Technical Specifications and Support

Complete Specifications

- **Input Voltage:** 5V 2A
- **Power:** 120W
- **Filtration System:** Dual-Layer (Stainless Steel Mesh + Washable HEPA Filter)
- **Filter Efficiency:** Captures 99.99% of fine particles as small as 0.3 microns
- **Body Material:** ABS Plastic
- **Warranty:** Please refer to the warranty card included in your package or contact the seller through your Amazon order page.

Environmental Note & Disposal

This product contains a rechargeable lithium-ion battery. At the end of its life, do not dispose of it with household waste. Please recycle or dispose of the battery and the unit according to your local electronic waste (e-waste) regulations to protect the environment.

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.

Document generated by [ManualsFile](#)