

Overview

The BEAUTURAL Mini Travel Steam Iron is a compact, dual-voltage appliance designed for travel and home use. It features temperature control, a non-stick soleplate, and a cord storage system. It is suitable for ironing clothes and for detailed craft work such as sewing and quilting.



Features and Specifications

Physical Specifications

- **Brand:** BEAUTURAL

- **Model Name:** Mini Iron
- **Model Number:** 1-MR08US07
- **Color:** Pink
- **Product Dimensions:** 5.5" L x 3.1" W
- **Item Weight:** 0.63 kg (1.39 lbs)
- **Base Material:** Stainless Steel (Non-Stick Soleplate)

Electrical Specifications

- **Wattage:** 420 Watts
- **Voltage:** 110 Volts (Dual Voltage: 110V-127V / 220V-240V)
- **Power Cord Length:** 6 feet
- **Heat-up Time:** Approximately 40 seconds

Key Features

- **Compact & Travel-Friendly:** Lightweight and small size for easy packing.
- **Dual Voltage:** Switchable for use worldwide. Includes a US plug.
- **Temperature Control:** Three settings for different fabric types (e.g., linen, cotton, silk, wool).
- **Steam Function:** Switch between dry and steam ironing. Features 5 steam outlets.
- **Non-Stick Soleplate:** Glides smoothly over fabrics.
- **Cord Storage:** Integrated system for winding the power cord.
- **Versatile Use:** Suitable for clothing, quilting, sewing, appliqué, and flower pressing.







Use Guide

Before First Use

1. Unwind the power cord completely.
2. Inspect the iron for any visible damage.
3. Wipe the soleplate with a soft, damp cloth to remove any dust.
4. Ensure your hands and the work surface are dry.

Setting the Voltage

Important: Before plugging in, verify the local voltage supply (e.g., 110V in the US, 220V in many other countries). This iron has automatic dual voltage (110V-127V / 220V-240V). No manual switch is required. Use a plug adapter if the outlet type differs from the included US plug.

Filling the Water Tank

1. Unplug the iron and ensure it is cool.

2. Hold the iron upright.
3. Open the water inlet cover.
4. Use a small cup or funnel to fill the tank with distilled or tap water. Do not overfill.
5. Close the cover securely.

Operating the Iron

1. **Plug In:** Connect the iron to a suitable power outlet.
2. **Select Temperature:** Turn the temperature control dial to the setting appropriate for your fabric.
 - **Low:** For delicate fabrics like silk and wool.
 - **Medium:** For synthetic fabrics.
 - **High:** For sturdy fabrics like cotton and linen.
3. **Heat Up:** Wait approximately 40 seconds for the iron to reach the selected temperature.
4. **Steam Function:** To use steam, flip the steam switch to the "ON" position once the iron is hot. Steam will emit from the 5 holes in the soleplate.
5. **Ironing:** Glide the iron over the fabric using gentle pressure. For vertical steaming, hold the iron slightly away from the fabric.



COMPACT SIZE

Perfect for Travel and Easy Storage



PERFECTLY SMOOTH FABRIC



After Use

1. Turn the temperature dial to the "OFF" or minimum position.
2. Unplug the iron from the wall outlet.
3. Empty any remaining water from the tank by holding the iron over a sink and tilting it.
4. Allow the iron to cool completely on a heat-resistant surface.
5. Wind the power cord using the integrated storage feature.
6. Store the iron in a dry place.

Care and Maintenance

- **Cleaning the Soleplate:** Wipe with a soft, damp cloth when cool. Do not use abrasive cleaners or scouring pads.
- **Descaling:** If you use hard water regularly, mineral deposits may build up. Use a commercial iron descaler according to its instructions, or a mixture of equal parts white vinegar and water. Run the steam function over a sink to flush the system, then rinse with clean water.

- **Storage:** Store in a cool, dry place. Ensure the cord is neatly wound.
- **Avoid:** Do not immerse the iron in water or any other liquid. Do not use chemical cleaners on the soleplate.

Troubleshooting

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in. Incorrect voltage setting for region.	Check power connection. Verify local voltage is within 110V-127V or 220V-240V range.
Little or no steam.	Water tank is empty. Temperature setting too low. Steam switch not on.	Fill water tank. Set temperature to High. Ensure steam switch is flipped to "ON".
Water leaks from iron.	Tank overfilled. Iron held at a wrong angle while steaming.	Do not fill past max line. Hold iron horizontally when using steam.
Soleplate is sticky or stained.	Fabric residue or starch buildup.	Clean cool soleplate with a damp cloth. For stubborn stains, use a paste of baking soda and water, then wipe clean.
Iron emits a burning smell.	New element heating for the first time. Incorrect fabric setting.	This may be normal during initial use. Ensure you are using the correct temperature setting for the fabric.

Safety Information

- Read all instructions before use.
- Use the iron only for its intended household purposes as described in this manual.
- To protect against electric shock, do not immerse the iron, cord, or plug in water or other liquids.
- The iron is hot when in use. Do not touch the soleplate. Keep away from children.
- Always unplug the iron from the electrical outlet when filling with water, when not in use, and before cleaning.
- Do not operate the iron if it has been dropped, damaged, or is leaking. Contact support.
- Do not leave the iron unattended while it is connected to the power supply.
- Use the iron on a stable, heat-resistant surface.
- The iron must be used and rested on a stable surface.

- When placing the iron on its stand, ensure the surface is stable.
 - This product is intended for indoor use only.
-

Compliance

This appliance complies with relevant safety standards. The included plug is designed for use in North America (110-127V). For use in other regions with 220-240V supply, a plug adapter may be required. The iron itself is compatible with both voltage ranges.

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.

Document generated by [ManualsFile](#)