

Important Safety Instructions

- This owner's guide and any additional inserts are considered part of the product. They contain important information about safety, use and disposal.
- Before using the product, please familiarize yourself with all operating and safety instructions.
- Please keep all documents for future reference and pass these documents on, together with the product, to any future owner. See our website to view, download and print the most current version of this owner's guide.

INTENDED USE:

- This product is intended to circulate the air in indoor living spaces only in the United States and Canada. This product is not intended for commercial or industrial use.
- The manufacturer assumes no responsibility for damage or injury due to unauthorized use or product modification. Failure to follow these directions will void the product warranty.

WARNING:

- Risk to Children and Impaired Persons
- Supervision is required during the installation, operation, cleaning and maintenance of this product by children under age 12 and anyone with reduced physical, sensory or mental capabilities.
- Children should be supervised to ensure that they do not play with the appliance, its parts and packaging material.

User Servicing Instructions

1. Using the product controls, turn off the appliance.
2. Grasp the plug (not the cord) and disconnect from the outlet.
3. Risk of Fire. Replace fuse only with 2.5 Amp, 125 Volt fuse as approved by Vornado Consumer Service. For an authorized replacement fuse, please contact Vornado Consumer Service.
4. Once the replacement is received, use a small flat-head screwdriver to slide open the fuse cover (located on the plug) (See Fig. A).
5. Remove fuse by using the screwdriver to gently lift each end of the fuse (See Fig. B).

Whole Room Circulation

MAXIMIZE YOUR COOLING EFFICIENCY

- A Vornado circulates all the air in the room so everyone is comfortable. Air in motion feels cooler than air that is stagnant.
- By providing whole room circulation, a Vornado allows you to turn the thermostat up 5°F – saving energy and money – without sacrificing comfort.



Feature




8 English

Circulation 101

GETTING THE MOST OUT OF YOUR VORNADO - ALL YEAR LONG

- With Vornado Air Circulators, you can save money on energy bills by adjusting your thermostat several degrees and still maintaining the same comfort level.



HOW TO USE


Before use, check appliance for visible damage. DO NOT USE THIS CIRCULATOR if there is evidence of damage. If any damage is found, contact Vornado Air LLC at 1-800-234-0604

1. Plug in and position the circulator so airflow is not obstructed.
2. Set desired speed and allow a few minutes for an airflow pattern to be established. Different airflow patterns can be established by changing the location, angle and speed. Adjust until a desired comfort level is achieved.

Cleaning

GRILL REMOVAL((Models 270, 279)

1. Remove the screw located at the 6 o'clock position.
2. Rotate the grill counter-clockwise to unlock and then lift off.
3. To reinstall the grill, position the grill with the logo slightly turned to the left and rotate clockwise. Replace the screw.



WARNING:

To reduce the risk of electrical shock and injury to persons, unplug the circulator before removing grill.

Note:


The motor is permanently lubricated and requires no oiling.

GRILL REMOVAL (Models 573, 673, 679)

1. Remove the 8 screws around the perimeter of the frame and lift off.
2. To reinstall the grill, line up screw holes and replace screw

BLADE REMOVAL

1. First, remove the nut from the shaft by turning the nut clockwise to loosen (model 573 has no nut). Pull the blade straight out from the shaft.
2. Wipe the Blade with a damp cloth. If your circulator is used in a greasy environment, such as a kitchen, mild soap or a common household cleaner may be necessary. Do not use solvents. Do not place blade in the dishwasher. The excessive heat can distort the plastic.
3. To reattach - be certain the flat side of the shaft aligns directly with the corresponding flat side on the blade's socket. Push the blade all the way on the shaft until it bottoms out. Do not use a hammer as this could result in bearing damage. Reinstall nut.



Troubleshooting

The unit fails to power on

- Unit is not plugged in. Plug Power Cord into electrical outlet. Ensure unit fan speed setting is selected. Plug fuse has blown.
- Replace fuse (See USER SERVICING INSTRUCTIONS on page 6). Unit is damaged or in need of repair. Cease usage and unplug.
- Contact Consumer Service for assistance. The outlet is worn or damaged. Try another outlet or contact a qualified electrician.

Airflow is weak or slow.

- Unit set to a low speed setting. Adjust to a higher speed setting. Airflow is blocked. Remove obstruction. Adjust direction of airflow towards the user.

GFCI has tripped.

- Under certain conditions, it is possible for a reset GFCI (Ground Fault Circuit Interrupter) outlet to trip when the user is changing speeds on a Vornado circulator.

- In this event, change to an outlet that is not connected to a GFCI device. It could also indicate a weak or defective GFCI outlet. Contact a qualified electrician to check the GFCI outlet.

Warranty

- Vornado Air LLC (“Vornado”) warrants to the original consumer or purchaser this Vornado® Whole Room Circulator (“Product”) is free from defects in material or workmanship for a period of five (5) years from the date of purchase. If any such defect is discovered within the warranty period, Vornado, at its discretion, will repair or replace the Product at no cost.
- For warranty or repair service: Call 1-800-234-0604 or email help@vornado.com to obtain a Return Authorization (“RA”) form.
- Please have or include your Product’s model number and serial number, as well as your name, address, city, state, zip code and phone number when contacting Vornado for warranty service. After receiving the RA form, ship your Product to:
- Vornado Air LLC Attn: Warranty & Repair 415 East 13th Street Andover, KS 67002. For your convenience, please have your model number and serial number when contacting Vornado with service inquiries. To assure proper handling, packages must be clearly marked with the RA number. Packages not clearly marked with the
- RA number may be refused at the receiving dock. Please allow 1-2 weeks for repair and return of your Product after the Product is received. Repairs not covered by the warranty or outside the warranty period will require a fee to cover the cost of materials, labor, handling and shipping.

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.