

Roku® TV Replacement Remote

User Manual



NOTE: If your remote is not operating properly, replace the batteries with new ones.

Setup

Preprogrammed for immediate use with Roku-enabled TVs. Simply insert two (2) AA batteries (not included) and you're ready to enjoy your favorite shows. Alkaline batteries are recommended for this remote.

"An Insignia or Sharp Roku-enabled TV may require programming. Additionally, if you wish to program the remote to operate a Roku streaming player rather than a Roku TV, please see the Programming Instructions section for details."

Battery Installation

1. Press arrow on back of remote and slide cover downward to remove.

2. Insert the batteries, making sure to match the (+) (–) polarity inside the compartment.
3. Replace cover and slide it upward until it clicks into place.

Battery Precautions

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH, etc.) batteries.
- Always remove old, weak or worn-out batteries promptly and recycle or dispose of them in accordance with local and national regulations.

Battery Saver

Your remote automatically turns off if the buttons are held down for more than 8 seconds. This saves battery life if your remote gets stuck in a place where the buttons remain depressed (e.g., between sofa cushions).

Code Saver

You have up to 10 minutes to change the batteries in your remote without losing the codes you have programmed.

Reset to Factory Settings


1. Press and hold the **SETUP** button until the red light stays on.
2. Press the **REWIND** button 4 times. The red light will blink twice.

Troubleshooting

Remote does not operate your device

- Make sure the batteries are fresh and installed correctly.
- Aim the remote directly at your device and make sure there are no obstructions between the remote and the device.
- Remote may not be compatible with your device.

Programming Instructions



Insignia and Sharp Roku TVs

Some Insignia and Sharp models may need additional programming. Use the included Code List and follow the steps below.

Roku Streaming Players

This remote can operate either a Roku TV or a Roku streaming player. It does not work with Roku streaming sticks. Programming is required for use with compatible Roku streaming players. Use the included Code List and follow the steps below.


1. In the Code List (included with remote), circle the 4-digit codes for the type and brand of device you wish to control.
2. Press and hold down the **SETUP** button until the remote's red light turns on.

3. Use the number buttons indicated in the diagram above to enter the first 4-digit code circled in Step 1. The red light will then turn off.
4. Point the remote at the device and test the buttons. If they don't work as expected, repeat Steps 2–4 with the next circled code.

Programming Notes

- Some codes may operate only a few device functions, so test other codes for more functionality.
- Keep your device codes for future reference.

Remote Button Overview



1. **Power** – Turns device ON/OFF
2. **Setup** – Used to program the remote
3. **Up/down/left/right** – Menu navigation

4. **OK** – Selects menu items
5. **Back** – Returns to previous menu/selection
6. **Home** – Returns to the home screen to access streaming features
7. **Options (*)** – Displays additional options
8. **Rewind, Play/Pause, Fast Forward**
9. **Volume up/down**
10. **Channel up/down**
11. **Mute** – Mutes sound
12. **App** – Accesses top apps like Netflix, Amazon Prime, Hulu and more
13. **Instant replay** – Repeats previous few seconds, then resumes play

FCC Statement

Supplier's Declaration of Conformity | Model #: 66814 | Jasco Products Co., 10 E. Memorial Rd., Oklahoma City, OK 73114, www.bjasco.com

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio/television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ICES-3(B)/NMB-3(B).

Customer Support

Register your product – Receive exclusive deals and register your product. Scan code or visit byjasco.com/deals.

Having Problems? Let us know how we can help. Call 1-800-654-8483 between 7AM–8PM, M–F, Central Time.

Like our product? Leave a review on your favorite retailer website or amazon.com.

For additional CE products, visit our website: www.bjasco.com

GE is a trademark of General Electric Company and is under license by Jasco Products Company LLC, 10 E. Memorial Rd., Oklahoma City, OK 73114. This Jasco product comes with a limited-lifetime warranty. Visit www.bjasco.com for warranty details.

MADE IN CHINA

66814 v1 1/22

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.

Document generated by [ManualsFile](https://ManualsFile.com)