


Pairing your remote with a Roku TV™




Step 1: Turn TV on

Stay on the Roku home screen.

Step 2: Insert batteries

On the back side of the remote, slide open the battery cover. Insert batteries placing the negative (-) ends in first.



Press and hold the Pairing button down for 5 seconds until you see the LED status light begin flashing.


Step 3: Pair

Point your new remote at your Roku TV and wait 30 seconds while the remote pairs.

NOTE: If the remote pairing dialog does not appear on your TV screen repeat steps 1 through 3.

Pairing your remote with a Roku player or Roku Smart Soundbar

See back page for “Pairing your remote with a Roku TV”



Step 1: Turn off Roku player


Remove the power cable from your player, wait 5 seconds, then re-connect it.

Step 2: Wait for home screen

When your Roku player displays the home screen, insert the batteries into your remote.

Step 3: Insert batteries

On the back side of the remote, slide open the battery cover. Insert batteries placing the negative (-) ends in first.



Press and hold the Pairing button down for 5 seconds until you see the LED status light begin flashing.

Step 4: Pair

Wait 30 seconds while your remote pairs with your player.

NOTE: If the remote pairing dialog does not appear on your TV screen repeat steps 1 through 4.

Setting up TV power and volume on my Roku player or audio device

1. Press the Home button on your new Roku remote.
2. Scroll up or down and select Settings.
3. Select Remotes & devices and then select Remote.

4. Select Set up remote for TV control. Follow the on-screen instructions.

Easy voice search



Search for your favorite entertainment, launch channels and turn on captions with one-touch access on your voice remote.

Here are a few things to try: “Launch the Roku Channel” “Show me comedies” “Launch Hulu”

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.

Document generated by [ManualsFile](#)