


## COMPATIBILITY


- Compatible with most mobile devices, including iPhones.
- If your device requires a different connector, use the cable that came with your device.

## FEATURES




## CHARGING YOUR PORTABLE BATTERY

Fully charge your portable battery before using it for the first time. This will take about nine hours.



1. Plug the small end of the included USB cable into the portable battery's micro USB port.
2. Plug the other end into a standard USB port on your computer, car charger, or wall charger (not included). The portable battery automatically begins charging and the LED turns on. **Note:** All four LEDs turn on when the portable battery is fully charged.

## CHARGING YOUR DEVICES



1. Plug the large end of the included USB cable into one of the portable battery's USB ports.
2. Plug the other end into your device. The portable battery automatically begins charging your device.

**Notes:**

- If your device requires a different connector than the one provided, use the cable that came with your device.
- You can charge two devices simultaneously, using both USB ports.
- Do not charge another device while your portable battery is charging.

**WARNING**

When using this product, basic precautions should always be followed, including the following:

- a) Read all the instructions before using the product.
- b) To reduce the risk of injury, close supervision is necessary when the product is used near children.
- c) Do not put fingers or hands into the product.
- d) Do not expose the power bank to rain or snow.
- e) Use of a power supply or charger not recommended or sold by the power pack manufacturer may result in a risk of fire or injury to persons.
- f) Do not use the power bank in excess of its output rating. Overload outputs above that rating may result in a risk of fire or injury to persons.
- g) Do not use a power bank that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior, resulting in fire, explosion or risk of injury.
- h) Do not disassemble the power bank. Take it to a qualified service person when service or repair are required. Incorrect reassembly may result in a risk of injury to persons.
- i) Do not expose a power pack to fire or excessive temperature. Exposure to fire or temperature above 100o C may cause explosion. The temperature of 100o C can be replaced by the temperature of 212o F .
- j) Have servicing performed by a qualified repair person using only identical replacement parts. This will ensure that the safety of the product is maintained.
- k) Switch off the power bank when not in use.

**SAFETY INFORMATION/CAUTION**

- Do not expose your portable battery to heat, fire, or water.
- Do not modify, disassemble, open, drop, crush, puncture, or shred the internal battery.
- This is not a toy. Young children should be supervised to make sure that they do not play with the portable battery .
- Do not charge devices while the portable battery is recharging.
- Recharge the portable battery if it has not been used for more than 90 days.

- Risk of fires and burns. Do not open, crush, heat above 140° F (60° C), or incinerate. Follow the manufacturer's instructions.
- Operating environment temperatures: 32~104° F (0~40° C) This product is safe for regular use under normal conditions. As with any device using electrical power, some situations may be unsafe and injuries or damages could result. To minimize or avoid unsafe conditions, read and follow the instructions before using.

## SPECIFICATIONS

<b>Dimensions</b> (H x W x D)	2.6 x 1.0 x 6.3 in. (66.0 X 25.4 X 160.0 mm)
<b>Cable length</b>	11.8 in. (300 mm)
<b>Input</b>	5 V, 2.4 A
<b>Output</b> USB and USB (QC 3.0)	USB :5 V, 2.4 A (12 W max) USB (QC 3.0) : 5 V,3 A 9 V,2 A 12 V,1.5 A(18 W max) USB + USB (QC 3.0):(30 W max)
<b>Power Bank Capacity</b>	13800 mAh / 69 Wh (5 V, 2.4 A) 13700 mAh / 68.5 Wh (5 V, 3 A) 7300 mAh / 65.7 Wh (9 V, 2 A) 5500 mAh / 66 Wh (12 V, 1.5 A)
<b>Built-in Cell Capacity</b>	20000 mAh / 74 Wh

### Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.